

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/YELLOW or WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE or BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	RED/WHITE or YELLOW/BLACK	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/RED or BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/RED	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	BLACK	At Light In Trunk
TACHOMETER WIRE	BROWN/WHITE	At Distributor
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLUE or BLUE/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/GRAY	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	WHITE/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/GRAY	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not required	METRA 70-7992, SCOSCHE SI03	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/YELLOW or WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE or BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	RED/WHITE or YELLOW/BLACK	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/RED or BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/RED	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	BLACK	At Light In Trunk
TACHOMETER WIRE	BROWN/WHITE	At Distributor
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLUE or BLUE/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/GRAY	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	WHITE/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/GRAY	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not required	METRA 70-7992, SCOSCHE SI03	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/YELLOW or WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE or BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	RED/WHITE or YELLOW/BLACK	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/RED or BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/RED	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	BLACK	At Light In Trunk
TACHOMETER WIRE	BROWN/WHITE	At Distributor
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLUE or BLUE/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/GRAY	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	WHITE/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/GRAY	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not required	METRA 70-7992, SCOSCHE SI03	Not required

Please verify all part numbers before ordering.