

TRIPLE S *Customs*

TOYOTA SUPRA 1985-1998 VEHICLE WIRING

WIRING INFORMATION: 1985 Toyota Supra

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	WHITE/BLUE	At Door Lock Switch In The Center Console
POWER DOOR UNLOCK (-)	YELLOW/RED	At Door Lock Switch In The Center Console
PARKING LIGHTS (+)	GREEN	Harness At Fuse Box
PARKING LIGHTS (-)	WHITE	Harness At Steering Column
DOOR TRIGGER (-)	RED/WHITE	Harness At Fuse Box
REAR HATCH TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM (-)	BLACK/WHITE	At Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM DISARM (-)	GREEN/RED	At Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE OR GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1986 Toyota Supra

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	WHITE/BLUE	At Door Lock Switch In The Center Console
POWER DOOR UNLOCK (-)	YELLOW/RED	At Door Lock Switch In The Center Console
PARKING LIGHTS (+)	GREEN	Harness At Fuse Box
PARKING LIGHTS (-)	WHITE	Harness At Steering Column
DOOR TRIGGER (-)	RED/WHITE	Harness At Fuse Box
REAR HATCH TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM (-)	BLACK/WHITE	At Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM DISARM (-)	GREEN/RED	At Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE OR GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1987 Toyota Supra

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED or WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
12V ACCESSORY WIRE	PINK/BLUE	Ignition Harness
POWER DOOR LOCK (-)	GREEN/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
REAR HATCH TRIGGER (-)	YELLOW/BLACK	Harness In Driver's Kick Panel
FACTORY ALARM ARM (-)	BROWN/YELLOW	Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	PURPLE/YELLOW	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	At Diagnostic Connector In Front Of Driver's Shock Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1988 Toyota Supra

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED or WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
12V ACCESSORY WIRE	PINK/BLUE	Ignition Harness
POWER DOOR LOCK (-)	GREEN/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	PINK	Harness In Steering Column
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
REAR HATCH TRIGGER (-)	YELLOW/BLACK	Harness In Driver's Kick Panel
FACTORY ALARM ARM (-)	BROWN/YELLOW	Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	PURPLE/YELLOW	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	At Diagnostic Connector In Front Of Driver's Shock Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1989 Toyota Supra

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED or WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
12V ACCESSORY WIRE	PINK/BLUE	Ignition Harness
POWER DOOR LOCK (-)	GREEN/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	PINK	Harness In Steering Column
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
REAR HATCH TRIGGER (-)	YELLOW/BLACK	Harness In Driver's Kick Panel
FACTORY ALARM ARM (-)	BROWN/YELLOW	Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	PURPLE/YELLOW	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	At Diagnostic Connector In Front Of Driver's Shock Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1990 Toyota Supra

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED or WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
12V ACCESSORY WIRE	PINK/BLUE	Ignition Harness
POWER DOOR LOCK (-)	GREEN/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	PINK	Harness In Steering Column
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
REAR HATCH TRIGGER (-)	YELLOW/BLACK	Harness In Driver's Kick Panel
FACTORY ALARM ARM (-)	BROWN/YELLOW	Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	PURPLE/YELLOW	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	At Diagnostic Connector In Front Of Driver's Shock Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1991 Toyota Supra

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED or WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
12V ACCESSORY WIRE	PINK/BLUE	Ignition Harness
POWER DOOR LOCK (-)	GREEN/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	PINK	Harness In Steering Column
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
REAR HATCH TRIGGER (-)	YELLOW/BLACK	Harness In Driver's Kick Panel
FACTORY ALARM ARM (-)	BROWN/YELLOW	Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	PURPLE/YELLOW	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	At Diagnostic Connector In Front Of Driver's Shock Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1992 Toyota Supra

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED or WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
12V ACCESSORY WIRE	PINK/BLUE	Ignition Harness
POWER DOOR LOCK (-)	GREEN/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	PINK	Harness In Steering Column
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
REAR HATCH TRIGGER (-)	YELLOW/BLACK	Harness In Driver's Kick Panel
FACTORY ALARM ARM (-)	BROWN/YELLOW	Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	PURPLE/YELLOW	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	At Diagnostic Connector In Front Of Driver's Shock Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1993 Toyota Supra

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED or WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
12V ACCESSORY WIRE	PINK/BLUE	Ignition Harness
POWER DOOR LOCK (-)	GREEN/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	PINK	Harness In Steering Column
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
REAR HATCH TRIGGER (-)	YELLOW/BLACK	Harness In Driver's Kick Panel
FACTORY ALARM ARM (-)	BROWN/YELLOW	Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	PURPLE/YELLOW	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	At Diagnostic Connector In Front Of Driver's Shock Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door

NOTE:

- For late 1993 models, use info for 1994 models.

WIRING INFORMATION 1994 Toyota Supra

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
12V ACCESSORY WIRE	GREEN	Ignition Harness
POWER DOOR LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	WHITE	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER (-)	RED/BLACK	Harness In Drivers Kick Panel
REAR HATCH TRIGGER (-)		Tied In With Doors
HOOD TRIGGER (-)	PURPLE/RED	High In Passenger Kick
FACTORY ALARM ARM	Arms With Lock	
FACTORY ALARM DISARM	Disarms With Unlock	
FACTORY ALARM DISARM NO UNLOCK (-)	WHITE or GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK (Non-turbo models) BLACK/WHITE (Turbo models)	At Igniter On Driver's Strut Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1995 Toyota Supra

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
12V ACCESSORY WIRE	GREEN	Ignition Harness
POWER DOOR LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	WHITE	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER (-)	RED/BLACK	Harness In Drivers Kick Panel
REAR HATCH TRIGGER (-)		Tied In With Doors
HOOD TRIGGER (-)	PURPLE/RED	High In Passenger Kick
FACTORY ALARM ARM	Arms With Lock	
FACTORY ALARM DISARM	Disarms With Unlock	
FACTORY ALARM DISARM NO UNLOCK (-)	WHITE or GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK (Non-turbo models) BLACK/WHITE (Turbo models)	At Igniter On Driver's Strut Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1996 Toyota Supra

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
12V ACCESSORY WIRE	GREEN	Ignition Harness
POWER DOOR LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	WHITE	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER (-)	RED/BLACK	Harness In Drivers Kick Panel
REAR HATCH TRIGGER (-)		Tied In With Doors
HOOD TRIGGER (-)	PURPLE/RED	High In Passenger Kick
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
FACTORY ALARM DISARM NO UNLOCK (-)	WHITE or GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK (Non-turbo models) BLACK/WHITE (Turbo models)	At Igniter On Driver's Strut Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1997 Toyota Supra

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
12V ACCESSORY WIRE	GREEN	Ignition Harness
POWER DOOR LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	WHITE	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER (-)	RED/BLACK	Harness In Drivers Kick Panel
REAR HATCH TRIGGER (-)		Tied In With Doors
HOOD TRIGGER (-)	PURPLE/RED	High In Passenger Kick
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
FACTORY ALARM DISARM NO UNLOCK (-)	WHITE or GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK (Non-turbo models) BLACK/WHITE (Turbo models)	At Igniter On Driver's Strut Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1998 Toyota Supra

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
12V ACCESSORY WIRE	GREEN	Ignition Harness
POWER DOOR LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	WHITE	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER (-)	RED/BLACK	Harness In Drivers Kick Panel
REAR HATCH TRIGGER (-)		Tied In With Doors
HOOD TRIGGER (-)	PURPLE/RED	High In Passenger Kick
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
FACTORY ALARM DISARM NO UNLOCK (-)	WHITE or GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK (Non-turbo models) BLACK/WHITE (Turbo models)	At Igniter On Driver's Strut Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door