

TRIPLE S *Customs*

**TOYOTA TACOMA 1995-2006
VEHICLE WIRING**

WIRING INFORMATION 1995 Toyota Tacoma

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	RED/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE	2 Wire Harness On Back Of Fuse Box
TACHOMETER WIRE	BLACK	V6 Models- Igniter On Passenger Side Of Engine Bay 4-Cylinder- Igniter On Driver Side Of Engine Bay
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/GREEN	In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	In Driver's Door

WIRING INFORMATION 1996 Toyota Tacoma

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	RED/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE	2 Wire Harness On Back Of Fuse Box
TACHOMETER WIRE	BLACK	V6 Models- Igniter On Passenger Side Of Engine Bay 4-Cylinder- Igniter On Driver Side Of Engine Bay
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/GREEN	In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	In Driver's Door

WIRING INFORMATION 1997 Toyota Tacoma

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	RED/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE	2 Wire Harness On Back Of Fuse Box
TACHOMETER WIRE	BLACK	V6 Models- Igniter On Passenger Side Of Engine Bay 4-Cylinder- Igniter On Driver Side Of Engine Bay
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/GREEN	In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	In Driver's Door

WIRING INFORMATION 1998 Toyota Tacoma

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	RED/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE	2 Wire Harness On Back Of Fuse Box
TACHOMETER WIRE	BLACK	V6 Models- Igniter On Passenger Side Of Engine Bay 4-Cylinder- Igniter On Driver Side Of Engine Bay
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/GREEN	In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	In Driver's Door

WIRING INFORMATION 1999 Toyota Tacoma

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	RED/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE	2 Wire Harness On Back Of Fuse Box
TACHOMETER WIRE	BLACK	V6 Models- Igniter On Passenger Side Of Engine Bay 4-Cylinder- Igniter On Driver Side Of Engine Bay
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/GREEN	In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	In Driver's Door

WIRING INFORMATION 2000 Toyota Tacoma

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	RED/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE	2 Wire Harness On Back Of Fuse Box
TACHOMETER WIRE	BLACK	V6 Models- Igniter On Passenger Side Of Engine Bay 4-Cylinder- Igniter On Driver Side Of Engine Bay
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/GREEN	In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	In Driver's Door

WIRING INFORMATION 2001 Toyota Tacoma

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE and WHITE/RED	Ignition harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition harness
SECOND IGNITION WIRE	BLACK/RED	Ignition harness
ACCESSORY WIRE	BLUE/RED	Ignition harness
STARTER WIRE	BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Harness On Back Of Fuse Box
POWER DOOR LOCK (-)	GRAY	Harness Next to Fuse Box
POWER DOOR UNLOCK (-)	PURPLE	Harness Next to Fuse Box
Test door lock wires by using the key in the door, not the rocker switch.		
DOOR TRIGGER (-)	GREEN (driver door) GREEN/WHITE (pass. door) YEL/GREEN (rear doors)	Big Harness Front Of Fuse Box
TACHOMETER WIRE	LT.GREEN/BLACK	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2002 Toyota Tacoma

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE and WHITE/RED	Ignition harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition harness
SECOND IGNITION WIRE	BLACK/RED	Ignition harness
ACCESSORY WIRE	BLUE/RED	Ignition harness
STARTER WIRE	BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Harness On Back Of Fuse Box
POWER DOOR LOCK (-)	GRAY	Harness Next to Fuse Box
POWER DOOR UNLOCK (-)	PURPLE	Harness Next to Fuse Box
Test door lock wires by using the key in the door, not the rocker switch.		
DOOR TRIGGER (-)	GREEN (driver door) GREEN/WHITE (pass. door) YEL/GREEN (rear doors)	Big Harness Front Of Fuse Box
TACHOMETER WIRE	LT.GREEN/BLACK	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2003 Toyota Tacoma

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE and WHITE/RED	Ignition harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition harness
SECOND IGNITION WIRE	BLACK/RED	Ignition harness
ACCESSORY WIRE	BLUE/RED	Ignition harness
STARTER WIRE	BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Harness On Back Of Fuse Box
POWER DOOR LOCK (-)	GRAY	Harness Next to Fuse Box
POWER DOOR UNLOCK (-)	PURPLE	Harness Next to Fuse Box
Test door lock wires by using the key in the door, not the rocker switch.		
DOOR TRIGGER (-)	GREEN (driver door) GREEN/WHITE (pass. door) YEL/GREEN (rear doors)	Big Harness Front Of Fuse Box
TACHOMETER WIRE	LT.GREEN/BLACK	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2004 Toyota Tacoma

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE and WHITE/RED	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition harness
ACCESSORY WIRE	BLUE/RED	Ignition harness
STARTER WIRE	BLACK	Ignition harness
KEY SENSE WIRE (-)	LT.GREEN/RED	Ignition harness
PARKING LIGHTS (+)	GREEN	Harness On Back Of Fuse Box
PARKING LIGHTS (-)	PURPLE/RED, RED, or YELLOW	Harness At Front Of Fuse Box
POWER DOOR LOCK (-)	GRAY	Harness At Front Of Fuse Box
POWER DOOR UNLOCK (-)	PURPLE	Harness At Front Of Fuse Box
Test door lock wires by using the key in the passenger door, not the rocker switch.		
LEFT FRONT DOOR TRIGGER (-)	GREEN	Harness At Front Of Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	GREEN/WHITE	
REAR DOORS TRIGGER (-)	YELLOW/GREEN	
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER WIRE	Wire that is NOT BLACK/YELLOW, BLACK/RED, or BROWN	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2005 Toyota Tacoma

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE and WHITE/RED	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
KEY SENSE WIRE (-)	GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	In 13-Pin Plug At Fuse Box
PARKING LIGHTS (-)	GREEN	At Module On Back Of Fuse Box
POWER DOOR LOCK (-)	PURPLE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/BLACK	Harness In Driver's Kick Panel
Test door lock wires while turning key in driver door. Unlock requires a double pulse		
DOOR TRIGGER (-)	GREEN/WHITE	At Module On Back Of Fuse Box
LEFT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	Driver Door Trigger And Rear Door Trigger Wires Are In An 18-Pin Plug. Right Front Door Trigger Is In A 22-Pin Plug On Back Of Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	RED/BLACK	
REAR DOORS TRIGGER (-)	PINK/BLACK	
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER WIRE	BLACK/WHITE	At Data Link Connector Under Driver's Dash
BRAKE WIRE (+)	BLUE	In 11-Pin Plug At Fuse Box
HORN TRIGGER (-)	GREEN/RED	In 18-Pin Plug At Fuse Box
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer that must be bypassed when installing a remote start system.		

WIRING INFORMATION 2006 Toyota Tacoma

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE and WHITE/RED	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
KEY SENSE WIRE (-)	GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	In 13-Pin Plug At Fuse Box
PARKING LIGHTS (-)	GREEN	At Module On Back Of Fuse Box
POWER DOOR LOCK (-)	PURPLE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/BLACK	Harness In Driver's Kick Panel
Test door lock wires while turning key in driver door. Unlock requires a double pulse		
DOOR TRIGGER (-)	GREEN/WHITE	At Module On Back Of Fuse Box
LEFT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	Driver Door Trigger And Rear Door Trigger Wires Are In An 18-Pin Plug. Right Front Door Trigger Is In A 22-Pin Plug On Back Of Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	RED/BLACK	
REAR DOORS TRIGGER (-)	PINK/BLACK	
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER WIRE	BLACK/WHITE	At Data Link Connector Under Driver's Dash
BRAKE WIRE (+)	BLUE	In 11-Pin Plug At Fuse Box
HORN TRIGGER (-)	GREEN/RED	In 18-Pin Plug At Fuse Box
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer that must be bypassed when installing a remote start system.		