

TRIPLE S *Customs*

TOYOTA TUNDRA 2000-2006 VEHICLE WIRING

WIRING INFORMATION: 2000 Toyota Tundra

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED OR WHITE	Ignition Harness
STARTER WIRE	GREEN/BLACK	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/GREEN	Wires Can Be Found In A Harness In Both The Driver's Kick Panel And In The Passenger Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Wires Can Be Found In A Harness In Both The Driver's Kick Panel And In The Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Drivers Kick Panel
HEADLIGHTS (-)	GREEN/YELLOW	Harness At Steering Column
DOOR TRIGGER (-)	WHITE/BLUE	Harness Coming Into Vehicle From Drivers Door
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	BLUE/BLACK	Drivers Door Harness
TACHOMETER WIRE	BLACK OR BLUE/WHITE	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 2001 Toyota Tundra

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED OR WHITE	Ignition Harness
STARTER WIRE	GREEN/BLACK	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/GREEN	Wires Can Be Found In A Harness In Both The Driver's Kick Panel And In The Passenger Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Wires Can Be Found In A Harness In Both The Driver's Kick Panel And In The Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Drivers Kick Panel
HEADLIGHTS (-)	GREEN/YELLOW	Harness At Steering Column
DOOR TRIGGER (-)	WHITE/BLUE	Harness Coming Into Vehicle From Drivers Door
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	BLUE/BLACK	Drivers Door Harness
TACHOMETER WIRE	BLACK OR BLUE/WHITE	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 2002 Toyota Tundra

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED OR WHITE	Ignition Harness
STARTER WIRE	GREEN/BLACK	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/GREEN	Wires Can Be Found In A Harness In Both The Driver's Kick Panel And In The Passenger Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Wires Can Be Found In A Harness In Both The Driver's Kick Panel And In The Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Drivers Kick Panel
HEADLIGHTS (-)	GREEN/YELLOW	Harness At Steering Column
DOOR TRIGGER (-)	WHITE/BLUE	Harness Coming Into Vehicle From Drivers Door
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	BLUE/BLACK	Drivers Door Harness
TACHOMETER WIRE	BLACK OR BLUE/WHITE	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 2003 Toyota Tundra

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED OR WHITE	Ignition Harness
STARTER WIRE	GREEN/BLACK	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/GREEN	Wires Can Be Found In A Harness In Both The Driver's Kick Panel And In The Passenger Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Wires Can Be Found In A Harness In Both The Driver's Kick Panel And In The Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Drivers Kick Panel
DOOR TRIGGER (-)	WHITE/BLUE	Harness Coming Into Vehicle From Drivers Door
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	BLUE/BLACK	Drivers Door Harness
TACHOMETER WIRE	BLACK OR BLUE/WHITE	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 2004 Toyota Tundra Double Cab

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	PINK	Ignition Harness
POWER DOOR LOCK	To interface with the door locks, refer to power door lock wires section in the Installation document.	
POWER DOOR UNLOCK		
PARKING LIGHTS (+)	GREEN	Harness In Drivers Kick Panel
DRIVER DOOR TRIGGER (-)	GRAY/RED	Module Above Driver's Kick Panel Close To Firewall
PASSENGER DOOR TRIGGER (-)	GREEN/BLACK	Module Above Driver's Kick Panel Close To Firewall
LEFT REAR DOOR TRIGGER (-)	RED/WHITE	Module Above Driver's Kick Panel Close To Firewall
RIGHT REAR DOOR TRIGGER (-)	RED/WHITE	Module Above Driver's Kick Panel Close To Firewall
HOOD TRIGGER (-)	BLUE/WHITE	At Factory Hood Pin
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
FACTORY DISARM NO UNLOCK (-)	YELLOW/GREEN	Key Sense Wire
TACHOMETER WIRE	WHITE/BLUE	At Module Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Switch
HORN TRIGGER (-)	BLACK/YELLOW	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Switch In Left Front Door
LEFT FRONT WINDOW DOWN	GREEN	At Switch In Left Front Door
RIGHT FRONT WINDOW UP	RED	At Switch In Right Front Door
RIGHT FRONT WINDOW DOWN	GREEN	At Switch In Right Front Door
LEFT REAR WINDOW UP	RED	At Switch In Left Rear Door
LEFT REAR WINDOW DOWN	GREEN	At Switch In Left Rear Door
RIGHT REAR WINDOW UP	RED	At Switch In Right Rear Door
RIGHT REAR WINDOW DOWN	GREEN	At Switch In Right Rear Door

WIRING INFORMATION: 2005 Toyota Tundra Double Cab

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	PINK	Ignition Harness
POWER DOOR LOCK	To interface with the door locks, refer to power door lock wires section in the Installation document.	
POWER DOOR UNLOCK		
PARKING LIGHTS (+)	GREEN	Harness In Drivers Kick Panel
DRIVER DOOR TRIGGER (-)	GRAY/RED	Module Above Driver's Kick Panel Close To Firewall
PASSENGER DOOR TRIGGER (-)	GREEN/BLACK	Module Above Driver's Kick Panel Close To Firewall
LEFT REAR DOOR TRIGGER (-)	RED/WHITE	Module Above Driver's Kick Panel Close To Firewall
RIGHT REAR DOOR TRIGGER (-)	RED/WHITE	Module Above Driver's Kick Panel Close To Firewall
HOOD TRIGGER (-)	BLUE/WHITE	At Factory Hood Pin
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
FACTORY DISARM NO UNLOCK (-)	YELLOW/GREEN	Key Sense Wire
TACHOMETER WIRE	WHITE/BLUE	At Module Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Switch
HORN TRIGGER (-)	BLACK/YELLOW	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Switch In Left Front Door
LEFT FRONT WINDOW DOWN	GREEN	At Switch In Left Front Door
RIGHT FRONT WINDOW UP	RED	At Switch In Right Front Door
RIGHT FRONT WINDOW DOWN	GREEN	At Switch In Right Front Door
LEFT REAR WINDOW UP	RED	At Switch In Left Rear Door
LEFT REAR WINDOW DOWN	GREEN	At Switch In Left Rear Door
RIGHT REAR WINDOW UP	RED	At Switch In Right Rear Door
RIGHT REAR WINDOW DOWN	GREEN	At Switch In Right Rear Door

WIRING INFORMATION: 2006 Toyota Tundra Double Cab

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	PINK	Ignition Harness
POWER DOOR LOCK	To interface with the door locks, refer to power door lock wires section in the Installation document.	
POWER DOOR UNLOCK		
PARKING LIGHTS (+)	GREEN	Harness In Drivers Kick Panel
DRIVER DOOR TRIGGER (-)	GRAY/RED	Module Above Driver's Kick Panel Close To Firewall
PASSENGER DOOR TRIGGER (-)	GREEN/BLACK	Module Above Driver's Kick Panel Close To Firewall
LEFT REAR DOOR TRIGGER (-)	RED/WHITE	Module Above Driver's Kick Panel Close To Firewall
RIGHT REAR DOOR TRIGGER (-)	RED/WHITE	Module Above Driver's Kick Panel Close To Firewall
HOOD TRIGGER (-)	BLUE/WHITE	At Factory Hood Pin
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
FACTORY DISARM NO UNLOCK (-)	YELLOW/GREEN	Key Sense Wire
TACHOMETER WIRE	WHITE/BLUE	At Module Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Switch
HORN TRIGGER (-)	BLACK/YELLOW	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Switch In Left Front Door
LEFT FRONT WINDOW DOWN	GREEN	At Switch In Left Front Door
RIGHT FRONT WINDOW UP	RED	At Switch In Right Front Door
RIGHT FRONT WINDOW DOWN	GREEN	At Switch In Right Front Door
LEFT REAR WINDOW UP	RED	At Switch In Left Rear Door
LEFT REAR WINDOW DOWN	GREEN	At Switch In Left Rear Door
RIGHT REAR WINDOW UP	RED	At Switch In Right Rear Door
RIGHT REAR WINDOW DOWN	GREEN	At Switch In Right Rear Door

WIRING INFORMATION: 2004 Toyota Tundra Single Cab

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED OR WHITE	Ignition Harness
STARTER WIRE	GREEN/BLACK or BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/GREEN or GREEN/BLACK	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	BLUE/RED	Harness In Drivers Kick Panel
Test door lock wires while using key in driver's door. Unlock requires a double pulse		
PARKING LIGHTS (+)	GREEN	Harness In Drivers Kick Panel
DOOR TRIGGER (-)	WHITE/BLUE	Harness Coming Into Vehicle From Drivers Door
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	PINK/BLACK	Ignition Key Sense Wire
TACHOMETER WIRE	BLACK OR BLUE/WHITE	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	LT.GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 2005 Toyota Tundra Single Cab

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED OR WHITE	Ignition Harness
STARTER WIRE	GREEN/BLACK or BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/GREEN or GREEN/BLACK	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	BLUE/RED	Harness In Drivers Kick Panel
Test door lock wires while using key in driver's door. Unlock requires a double pulse		
PARKING LIGHTS (+)	GREEN	Harness In Drivers Kick Panel
DOOR TRIGGER (-)	WHITE/BLUE	Harness Coming Into Vehicle From Drivers Door
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	PINK/BLACK	Ignition Key Sense Wire
TACHOMETER WIRE	BLACK OR BLUE/WHITE	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	LT.GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 2006 Toyota Tundra Single Cab

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED OR WHITE	Ignition Harness
STARTER WIRE	GREEN/BLACK or BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/GREEN or GREEN/BLACK	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	BLUE/RED	Harness In Drivers Kick Panel
Test door lock wires while using key in driver's door. Unlock requires a double pulse		
PARKING LIGHTS (+)	GREEN	Harness In Drivers Kick Panel
DOOR TRIGGER (-)	WHITE/BLUE	Harness Coming Into Vehicle From Drivers Door
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	PINK/BLACK	Ignition Key Sense Wire
TACHOMETER WIRE	BLACK OR BLUE/WHITE	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	LT.GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door