

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	RED/BLACK	Ignition Harness
12V IGNITION WIRE	BLACK	Ignition Harness
12V ACCESSORY WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	YELLOW/RED or GRAY	In Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	RED/BLACK or GREEN	In Harness In Driver's Kick Panel

Notes: Unlock requires a double pulse.

PARKING LIGHTS (+)	GRAY/RED (LEFT) GRAY/BLACK (RIGHT)	At Headlight Switch
--------------------	---------------------------------------	---------------------

Notes: Use both parking light wires and diode isolate,

DOOR TRIGGER (-)	BROWN/WHITE	In Harness In Driver's Kick Panel OR At OEM Alarm Module Behind Headlight Switch
TRUNK TRIGGER (-)	BROWN/BLACK	In Harness In Driver's Kick Panel OR At OEM Alarm Module Behind Headlight Switch
TRUNK RELEASE (5-wire)	GRAY	At Switch
HOOD TRIGGER (-)	BROWN/RED	Behind Fuse Box
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock

Notes: Single pulse to unlock wire will disarm factory security without unlocking the doors.

TACHOMETER WIRE	RED/BLACK or BLACK/PURPLE	At Coil Pack On Right Side Of Motor
BRAKE WIRE (+)	RED/BLACK	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK/YELLOW	Behind Fuse Box
LEFT FRONT WINDOW UP	No access to wires. Motor is part of window module.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	ORANGE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/BLACK	At Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/WHITE	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE/WHITE	At Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED/LIGHT GREEN	At Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/LIGHT GREEN	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE/RED	At Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1784, SCOSCHE VW01B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	RED/BLACK	Ignition Harness
12V IGNITION WIRE	BLACK	Ignition Harness
12V ACCESSORY WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	YELLOW/RED or GRAY	In Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	RED/BLACK or GREEN	In Harness In Driver's Kick Panel

Notes: Unlock requires a double pulse.

PARKING LIGHTS (+)	GRAY/RED (LEFT) GRAY/BLACK (RIGHT)	At Headlight Switch
--------------------	---------------------------------------	---------------------

Notes: Use both parking light wires and diode isolate,

DOOR TRIGGER (-)	BROWN/WHITE	In Harness In Driver's Kick Panel OR At OEM Alarm Module Behind Headlight Switch
TRUNK TRIGGER (-)	BROWN/BLACK	In Harness In Driver's Kick Panel OR At OEM Alarm Module Behind Headlight Switch
TRUNK RELEASE (5-wire)	GRAY	At Switch
HOOD TRIGGER (-)	BROWN/RED	Behind Fuse Box
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock

Notes: Single pulse to unlock wire will disarm factory security without unlocking the doors.

TACHOMETER WIRE	RED/BLACK or BLACK/PURPLE	At Coil Pack On Right Side Of Motor
BRAKE WIRE (+)	RED/BLACK	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK/YELLOW	Behind Fuse Box
LEFT FRONT WINDOW UP	No access to wires. Motor is part of window module.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	ORANGE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/BLACK	At Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/WHITE	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE/WHITE	At Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED/LIGHT GREEN	At Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/LIGHT GREEN	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE/RED	At Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1784, SCOSCHE VW01B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	RED/BLACK	Ignition Harness
12V IGNITION WIRE	BLACK	Ignition Harness
12V ACCESSORY WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	YELLOW/RED or GRAY	In Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	RED/BLACK or GREEN	In Harness In Driver's Kick Panel

Notes: Unlock requires a double pulse.

PARKING LIGHTS (+)	GRAY/RED (LEFT) GRAY/BLACK (RIGHT)	At Headlight Switch
--------------------	---------------------------------------	---------------------

Notes: Use both parking light wires and diode isolate,

DOOR TRIGGER (-)	BROWN/WHITE	In Harness In Driver's Kick Panel OR At OEM Alarm Module Behind Headlight Switch
TRUNK TRIGGER (-)	BROWN/BLACK	In Harness In Driver's Kick Panel OR At OEM Alarm Module Behind Headlight Switch
TRUNK RELEASE (5-wire)	GRAY	At Switch
HOOD TRIGGER (-)	BROWN/RED	Behind Fuse Box
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock

Notes: Single pulse to unlock wire will disarm factory security without unlocking the doors.

TACHOMETER WIRE	RED/BLACK or BLACK/PURPLE	At Coil Pack On Right Side Of Motor
BRAKE WIRE (+)	RED/BLACK	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK/YELLOW	Behind Fuse Box
LEFT FRONT WINDOW UP	No access to wires. Motor is part of window module.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	ORANGE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/BLACK	At Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/WHITE	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE/WHITE	At Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED/LIGHT GREEN	At Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/LIGHT GREEN	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE/RED	At Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1784, SCOSCHE VW01B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	RED/BLACK	Ignition Harness
12V IGNITION WIRE	BLACK	Ignition Harness
12V ACCESSORY WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	YELLOW/RED or GRAY	In Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	RED/BLACK or GREEN	In Harness In Driver's Kick Panel

Notes: Unlock requires a double pulse.

PARKING LIGHTS (+)	GRAY/RED (LEFT) GRAY/BLACK (RIGHT)	At Headlight Switch
--------------------	---------------------------------------	---------------------

Notes: Use both parking light wires and diode isolate,

DOOR TRIGGER (-)	BROWN/WHITE	In Harness In Driver's Kick Panel OR At OEM Alarm Module Behind Headlight Switch
TRUNK TRIGGER (-)	BROWN/BLACK	In Harness In Driver's Kick Panel OR At OEM Alarm Module Behind Headlight Switch
TRUNK RELEASE (5-wire)	GRAY	At Switch
HOOD TRIGGER (-)	BROWN/RED	Behind Fuse Box
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock

Notes: Single pulse to unlock wire will disarm factory security without unlocking the doors.

TACHOMETER WIRE	RED/BLACK or BLACK/PURPLE	At Coil Pack On Right Side Of Motor
BRAKE WIRE (+)	RED/BLACK	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK/YELLOW	Behind Fuse Box
LEFT FRONT WINDOW UP	No access to wires. Motor is part of window module.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	ORANGE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/BLACK	At Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/WHITE	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE/WHITE	At Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED/LIGHT GREEN	At Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/LIGHT GREEN	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE/RED	At Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1784, SCOSCHE VW01B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	RED/BLACK	Ignition Harness
12V IGNITION WIRE	BLACK	Ignition Harness
12V ACCESSORY WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	YELLOW/RED or GRAY	In Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	RED/BLACK or GREEN	In Harness In Driver's Kick Panel

Notes: Unlock requires a double pulse.

PARKING LIGHTS (+)	GRAY/RED (LEFT) GRAY/BLACK (RIGHT)	At Headlight Switch
--------------------	---------------------------------------	---------------------

Notes: Use both parking light wires and diode isolate,

DOOR TRIGGER (-)	BROWN/WHITE	In Harness In Driver's Kick Panel OR At OEM Alarm Module Behind Headlight Switch
TRUNK TRIGGER (-)	BROWN/BLACK	In Harness In Driver's Kick Panel OR At OEM Alarm Module Behind Headlight Switch
TRUNK RELEASE (5-wire)	GRAY	At Switch
HOOD TRIGGER (-)	BROWN/RED	Behind Fuse Box
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock

Notes: Single pulse to unlock wire will disarm factory security without unlocking the doors.

TACHOMETER WIRE	RED/BLACK or BLACK/PURPLE	At Coil Pack On Right Side Of Motor
BRAKE WIRE (+)	RED/BLACK	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK/YELLOW	Behind Fuse Box
LEFT FRONT WINDOW UP	No access to wires. Motor is part of window module.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	ORANGE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/BLACK	At Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/WHITE	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE/WHITE	At Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED/LIGHT GREEN	At Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/LIGHT GREEN	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE/RED	At Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1784, SCOSCHE VW01B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	RED/BLACK	Ignition Harness
12V IGNITION WIRE	BLACK	Ignition Harness
12V ACCESSORY WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	YELLOW/RED or GRAY	In Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	RED/BLACK or GREEN	In Harness In Driver's Kick Panel

Notes: Unlock requires a double pulse.

PARKING LIGHTS (+)	GRAY/RED (LEFT) GRAY/BLACK (RIGHT)	At Headlight Switch
--------------------	---------------------------------------	---------------------

Notes: Use both parking light wires and diode isolate,

DOOR TRIGGER (-)	BROWN/WHITE	In Harness In Driver's Kick Panel OR At OEM Alarm Module Behind Headlight Switch
TRUNK TRIGGER (-)	BROWN/BLACK	In Harness In Driver's Kick Panel OR At OEM Alarm Module Behind Headlight Switch
TRUNK RELEASE (5-wire)	GRAY	At Switch
HOOD TRIGGER (-)	BROWN/RED	Behind Fuse Box
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock

Notes: Single pulse to unlock wire will disarm factory security without unlocking the doors.

TACHOMETER WIRE	RED/BLACK or BLACK/PURPLE	At Coil Pack On Right Side Of Motor
BRAKE WIRE (+)	RED/BLACK	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK/YELLOW	Behind Fuse Box
LEFT FRONT WINDOW UP	No access to wires. Motor is part of window module.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	ORANGE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/BLACK	At Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/WHITE	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE/WHITE	At Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED/LIGHT GREEN	At Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/LIGHT GREEN	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE/RED	At Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1784, SCOSCHE VW01B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	RED/BLACK or RED/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK	Ignition Harness
12V ACCESSORY WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	GRAY	At OEM Alarm Module Under Driver's Side Dash
POWER DOOR UNLOCK (+)	RED/BLACK or GREEN	At OEM Alarm Module Under Driver's Side Dash
Notes: Unlock requires a double pulse.		
PARKING LIGHTS (+)	GRAY/BLACK (LEFT) GRAY/RED (RIGHT)	At Headlight Switch
Notes: Use both parking light wires and diode isolate.		
DOOR TRIGGER (-)	BROWN/WHITE	In Driver's Kick Panel OR At OEM Alarm Module Under Driver's Side Dash
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN/RED	At OEM Alarm Module Under Driver's Side Dash
TRUNK RELEASE (-)	GRAY/GREEN	At Switch
HOOD TRIGGER (-)	BROWN/RED	Behind Fuse Box
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
TACHOMETER WIRE	BLACK/RED	At Ignition Coil
BRAKE WIRE (+)	RED/BLACK	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK/YELLOW	At OEM Alarm Module Under Driver's Side Dash
LEFT FRONT WINDOW UP	No access to wires. Motor is part of window module.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED	ORANGE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/BLACK	At Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/WHITE	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE/WHITE	At Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED/LIGHT GREEN	At Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/LIGHT GREEN	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE/RED	At Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1784, SCOSCHE VW01B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	RED/BLACK or RED/WHITE	Ignition Harness
12V IGNITION WIRE	BLACK	Ignition Harness
12V ACCESSORY WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	GRAY	At OEM Alarm Module Under Driver's Side Dash
POWER DOOR UNLOCK (+)	RED/BLACK or GREEN	At OEM Alarm Module Under Driver's Side Dash
Notes: Unlock requires a double pulse.		
PARKING LIGHTS (+)	GRAY/BLACK (LEFT) GRAY/RED (RIGHT)	At Headlight Switch
Notes: Use both parking light wires and diode isolate.		
DOOR TRIGGER (-)	BROWN/WHITE	In Driver's Kick Panel OR At OEM Alarm Module Under Driver's Side Dash
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN/RED	At OEM Alarm Module Under Driver's Side Dash
TRUNK RELEASE (-)	GRAY/GREEN	At Switch
HOOD TRIGGER (-)	BROWN/RED	Behind Fuse Box
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
TACHOMETER WIRE	BLACK/RED	At Ignition Coil
BRAKE WIRE (+)	RED/BLACK	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK/YELLOW	At OEM Alarm Module Under Driver's Side Dash
LEFT FRONT WINDOW UP	No access to wires. Motor is part of window module.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED	ORANGE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/BLACK	At Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/WHITE	At Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE/WHITE	At Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED/LIGHT GREEN	At Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	ORANGE/BLACK	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/LIGHT GREEN	At Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE/RED	At Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1784, SCOSCHE VW01B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			