

TRIPLE S *Customs*

CHEVROLET MONTE CARLO 1995-2005 VEHICLE WIRING

WIRING INFORMATION: 1995 Chevy Monte Carlo

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	PINK	Ignition harness
SECOND IGNITION WIRE	PURPLE	Ignition harness
ACCESSORY WIRE	ORANGE	Ignition harness
POWER DOOR LOCK (+)	LT. BLUE	Harness Coming Into Vehicle From Driver's Door Or Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	WHITE	Harness Coming Into Vehicle From Driver's Door Or Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Running Towards Vehicle Rear Or Headlight Light Switch
DOOR TRIGGER WIRE (-)	BLUE	Harness In Driver's Kick Panel Running Towards Vehicle Rear Or Light Switch
TRUNK RELEASE WIRE (+)	BLACK or BLACK/WHITE	Trunk Release switch
TRUNK TRIGGER WIRE (-)	RED/BLACK	Light In Trunk
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	WHITE	Plug At Brake Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system.

WIRING INFORMATION: 1996 Chevy Monte Carlo

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	PINK	Ignition harness
SECOND IGNITION WIRE	PURPLE	Ignition harness
ACCESSORY WIRE	ORANGE	Ignition harness
POWER DOOR LOCK (+)	LT. BLUE	Harness Coming Into Vehicle From Driver's Door Or Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	WHITE	Harness Coming Into Vehicle From Driver's Door Or Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Running Towards Vehicle Rear Or Headlight Light Switch
DOOR TRIGGER WIRE (-)	BLUE	Harness In Driver's Kick Panel Running Towards Vehicle Rear Or Headlight Light Switch
TRUNK RELEASE WIRE (+)	BLACK or BLACK/WHITE	Trunk Release switch
TRUNK TRIGGER WIRE (-)	RED/BLACK	Light In Trunk
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	WHITE	Plug At Brake Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 1997 Chevy Monte Carlo

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	PINK	Ignition harness
SECOND IGNITION WIRE	PURPLE	Ignition harness
ACCESSORY WIRE	ORANGE	Ignition harness
POWER DOOR LOCK (+)	LT. BLUE	Harness Coming Into Vehicle From Driver's Door Or Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	WHITE	Harness Coming Into Vehicle From Driver's Door Or Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Running Towards Vehicle Rear Or Headlight Light Switch
DOOR TRIGGER WIRE (-)	BLUE	Harness In Driver's Kick Panel Running Towards Vehicle Rear Or Headlight Light Switch
TRUNK RELEASE WIRE (+)	BLACK or BLACK/WHITE	Trunk Release switch
TRUNK TRIGGER WIRE (-)	RED/BLACK	Light In Trunk
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	WHITE	Plug At Brake Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 1998 Chevy Monte Carlo

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	PINK	Ignition harness
SECOND IGNITION WIRE	PURPLE	Ignition harness
ACCESSORY WIRE	ORANGE	Ignition harness
POWER DOOR LOCK (+)	LT. BLUE	Harness Coming Into Vehicle From Driver's Door Or Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	WHITE	Harness Coming Into Vehicle From Driver's Door Or Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Running Towards Vehicle Rear Or Headlight Light Switch
DOOR TRIGGER WIRE (-)	BLUE	Harness In Driver's Kick Panel Running Towards Vehicle Rear Or Headlight Light Switch
TRUNK RELEASE WIRE (+)	BLACK or BLACK/WHITE	Trunk Release switch
TRUNK TRIGGER WIRE (-)	RED/BLACK	Light In Trunk
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	WHITE	Plug At Brake Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 1999 Chevy Monte Carlo

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	PINK	Ignition harness
SECOND IGNITION WIRE	PURPLE	Ignition harness
ACCESSORY WIRE	ORANGE	Ignition harness
POWER DOOR LOCK (+)	LT. BLUE	Harness Coming Into Vehicle From Driver's Door Or Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	WHITE	Harness Coming Into Vehicle From Driver's Door Or Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Running Towards Vehicle Rear Or Headlight Light Switch
DOOR TRIGGER WIRE (-)	BLUE	Harness In Driver's Kick Panel Running Towards Vehicle Rear Or Headlight Light Switch
TRUNK RELEASE WIRE (+)	BLACK or BLACK/WHITE	Trunk Release switch
TRUNK TRIGGER WIRE (-)	RED/BLACK	Light In Trunk
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	WHITE	Plug At Brake Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2000 Chevy Monte Carlo

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	PINK	Ignition harness
SECOND ACCESSORY WIRE	GREEN	Ignition harness
ACCESSORY WIRE	ORANGE	Ignition harness
SECOND ACCESSORY	BROWN	Ignition harness
When installing a remote start system, the BROWN accessory wire must be energized as an accessory wire. If it is energized as an ignition wire, the engine will not crank.		
POWER DOOR LOCK (negative trigger through a 470-ohm resistor)	ORANGE/BLACK	Body Control Module Above Brake Pedal
POWER DOOR UNLOCK (negative trigger)	Same wire as lock	
PARKING LIGHTS (-)	WHITE	Body Control Module Above Brake Pedal
DRIVER DOOR TRIGGER WIRE (-)	BLUE	Body Control Module Above Brake Pedal
PASSENGER DOOR TRIGGER (-)	BLUE/WHITE	Body Control Module
TRUNK RELEASE WIRE (-)	BLACK	Trunk Release switch
TRUNK TRIGGER WIRE (-)	RED/BLACK	Body Control Module Above Brake Pedal
FACTORY ALARM DISARM WIRE (-)	LT.GREEN	Body Control Module Above Brake Pedal
TACHOMETER WIRE	WHITE	Ignition coil
BRAKE WIRE (+)	WHITE	Plug at Brake Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the Passlock II anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2001 Chevy Monte Carlo

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	PINK	Ignition harness
SECOND ACCESSORY WIRE	GREEN	Ignition harness
ACCESSORY WIRE	ORANGE	Ignition harness
SECOND ACCESSORY	BROWN	Ignition harness
When installing a remote start system, the BROWN accessory wire must be energized as an accessory wire. If it is energized as an ignition wire, the engine will not crank.		
POWER DOOR LOCK (negative trigger through a 470-ohm resistor)	ORANGE/BLACK	Body Control Module Above Brake Pedal
POWER DOOR UNLOCK (negative trigger)	Same wire as lock	
PARKING LIGHTS (-)	WHITE	Body Control Module Above Brake Pedal
DRIVER DOOR TRIGGER WIRE (-)	BLUE	Body Control Module Above Brake Pedal
PASSENGER DOOR TRIGGER (-)	BLUE/WHITE	Body Control Module
TRUNK RELEASE WIRE (-)	BLACK	Trunk Release switch
TRUNK TRIGGER WIRE (-)	RED/BLACK	Body Control Module Above Brake Pedal
FACTORY ALARM DISARM WIRE (-)	LT.GREEN	Body Control Module Above Brake Pedal
TACHOMETER WIRE	WHITE	Ignition coil
BRAKE WIRE (+)	WHITE	Plug at Brake Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the Passlock II anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2002 Chevy Monte Carlo

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	PINK	Ignition harness
SECOND ACCESSORY WIRE	GREEN	Ignition harness
ACCESSORY WIRE	ORANGE	Ignition harness
SECOND ACCESSORY	BROWN	Ignition harness
When installing a remote start system, the BROWN accessory wire must be energized as an accessory wire. If it is energized as an ignition wire, the engine will not crank.		
POWER DOOR LOCK (negative trigger through a 470-ohm resistor)	ORANGE/BLACK	Body Control Module Above Brake Pedal
POWER DOOR UNLOCK (negative trigger)	Same wire as lock	
PARKING LIGHTS (-)	WHITE	Body Control Module Above Brake Pedal
DRIVER DOOR TRIGGER WIRE (-)	BLUE	Body Control Module Above Brake Pedal
PASSENGER DOOR TRIGGER (-)	BLUE/WHITE	Body Control Module
TRUNK RELEASE WIRE (-)	BLACK	Trunk Release switch
TRUNK TRIGGER WIRE (-)	RED/BLACK	Body Control Module Above Brake Pedal
FACTORY ALARM DISARM WIRE (-)	LT.GREEN	Body Control Module Above Brake Pedal
TACHOMETER WIRE	WHITE	Ignition coil
BRAKE WIRE (+)	WHITE	Plug at Brake Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the Passlock II anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2003 Chevy Monte Carlo

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	PINK	Ignition harness
SECOND ACCESSORY WIRE	GREEN	Ignition harness
ACCESSORY WIRE	ORANGE	Ignition harness
SECOND ACCESSORY	BROWN	Ignition harness
When installing a remote start system, the BROWN accessory wire must be energized as an accessory wire. If it is energized as an ignition wire, the engine will not crank.		
POWER DOOR LOCK (negative trigger through a 470-ohm resistor)	ORANGE/BLACK	Body Control Module Above Brake Pedal
POWER DOOR UNLOCK (negative trigger)	Same wire as lock	
PARKING LIGHTS (-)	WHITE	Body Control Module Above Brake Pedal
DRIVER DOOR TRIGGER WIRE (-)	BLUE	Body Control Module Above Brake Pedal
PASSENGER DOOR TRIGGER (-)	BLUE/WHITE	Body Control Module
TRUNK RELEASE WIRE (-)	BLACK	Trunk Release switch
TRUNK TRIGGER WIRE (-)	RED/BLACK	Body Control Module Above Brake Pedal
FACTORY ALARM DISARM WIRE (-)	LT.GREEN	Body Control Module Above Brake Pedal
TACHOMETER WIRE	WHITE	Ignition coil
BRAKE WIRE (+)	WHITE	Plug at Brake Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the Passlock II anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2004 Chevy Monte Carlo

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	PINK	Ignition harness
SECOND ACCESSORY WIRE	GREEN	Ignition harness
ACCESSORY WIRE	ORANGE	Ignition harness
SECOND ACCESSORY	BROWN	Ignition harness
When installing a remote start system, the BROWN accessory wire must be energized as an accessory wire. If it is energized as an ignition wire, the engine will not crank.		
POWER DOOR LOCK (negative trigger through a 470-ohm resistor)	ORANGE/BLACK	Body Control Module Above Brake Pedal
POWER DOOR UNLOCK (negative trigger)	Same wire as lock	
PARKING LIGHTS (-)	WHITE	Body Control Module Above Brake Pedal
The parking light wire must be relay isolated from the BCM to avoid the service engine soon light from coming on.		
DRIVER DOOR TRIGGER WIRE (-)	BLUE	Body Control Module Above Brake Pedal
PASSENGER DOOR TRIGGER WIRE (-)	BLUE/WHITE	Body Control Module
TRUNK RELEASE WIRE (-)	BLACK	Trunk Release switch
TRUNK TRIGGER WIRE (-)	RED/BLACK	Body Control Module Above Brake Pedal
FACTORY ALARM DISARM WIRE (-)	LT.GREEN	Body Control Module Above Brake Pedal
TACHOMETER WIRE	WHITE	Ignition coil
BRAKE WIRE (+)	WHITE	Plug at Brake Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the Passlock II anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2005 Chevy Monte Carlo

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	PINK	Ignition harness
SECOND ACCESSORY WIRE	GREEN	Ignition harness
ACCESSORY WIRE	ORANGE	Ignition harness
SECOND ACCESSORY	BROWN	Ignition harness
When installing a remote start system, the BROWN accessory wire must be energized as an accessory wire. If it is energized as an ignition wire, the engine will not crank.		
POWER DOOR LOCK (negative trigger through a 470-ohm resistor)	ORANGE/BLACK	Body Control Module Above Brake Pedal
POWER DOOR UNLOCK (negative trigger)	Same wire as lock	
PARKING LIGHTS (-)	WHITE	Body Control Module Above Brake Pedal
The parking light wire must be relay isolated from the BCM to avoid the service engine soon light from coming on.		
DRIVER DOOR TRIGGER WIRE (-)	BLUE	Body Control Module Above Brake Pedal
PASSENGER DOOR TRIGGER WIRE (-)	BLUE/WHITE	Body Control Module
TRUNK RELEASE WIRE (-)	BLACK	Trunk Release switch
TRUNK TRIGGER WIRE (-)	RED/BLACK	Body Control Module Above Brake Pedal
FACTORY ALARM DISARM WIRE (-)	LT.GREEN	Body Control Module Above Brake Pedal
TACHOMETER WIRE	WHITE	Ignition coil
BRAKE WIRE (+)	WHITE	Plug at Brake Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the Passlock II anti-theft system. This must be bypassed when installing a remote start system.		