

ALARM & REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE 1	RED/WHITE or WHITE/RED	Ignition Harness
STARTER WIRE 2	WHITE/GREEN	Ignition Harness
IGNITION WIRE 1	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	WHITE/BLACK	Ignition Harness
FACTRY ALARM ARM	Arms With Lock	
FACTRY ALARM DISARM	Disarms With Unlock	
DISARM NO UNLOCK	Single Pulse On The Unlock Wire Will Disarm The Alarm Without Unlocking The Doors	
TACHOMETER WIRE	Any Wire NOT BLACK Or WHITE/BLUE	At Ignition Coil
BRAKE WIRE (+)	LT.GREEN/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
POWER DOOR LOCK (-)	YELLOW	At Module Inside Driver's Door
NOTE: Test door lock wires while turning the key in the driver's door. Unlock requires a double pulse.		
POWER DOOR UNLOCK (-)	LIGHT BLUE	At Module Inside Driver's Door
NOTE: Extended triggers on the power door lock wires will operate the power windows.		
TRUNK RELEASE (-)	BLUE	Brown Connector At Body Control Module In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel Running Towards Rear Of Vehicle
ALL DOOR TRIGGER (-)		
LEFT FRONT DOOR TRIGGER (-)	YELLOW	At Body Control Module In Driver's Kick Panel
RIGHT FRONT DOOR TRIGGER (-)	PINK	At Body Control Module In Driver's Kick Panel
DOMESUPERVISION	Dome light comes on with unlock	
TRUNK TRIGGER (-)	RED/WHITE	White Connector At Body Control Module In Driver's Kick Panel
HOOD TRIGGER (-)	LT GREEN/BLACK	Pin Switch Under Hood

ALARM & REMOTE START INTERFACE MODULES

MODULE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AMPLIFIED AUDIO WIRING

WIRE	COLOR	LOCATION
RADIO 12V	YELLOW	Radio Harness
RADIO SWITCHED	LIGHT GREEN	Radio Harness
RADIO GROUND		Ground to chassis
ILLUMINATION (+)	RED/YELLOW	Radio Harness
POWER ANTENNA (+)	GREEN/WHITE	Radio Harness
AMP TURN ON	GREEN/YELLOW	Radio Harness
LEFT FRONT TO AMP (+)	WHITE	Radio Harness
LEFT FRONT TO AMP (-)	BLACK	Radio Harness
RIGHT FRONT TO AMP (+)	GREEN	Radio Harness
RIGHT FRONT TO AMP (-)	RED	Radio Harness
LEFT REAR TO AMP (+)	BROWN	Radio Harness
LEFT REAR TO AMP (-)	YELLOW	Radio Harness
RIGHT REAR TO AMP (+)	BLUE	Radio Harness
RIGHT REAR TO AMP (-)	PINK	Radio Harness
LEFT FRONT SPEAKERS (+)	GREEN	At Bose Amplifier Under Rear Deck
LEFT FRONT SPEAKERS (-)	RED	At Bose Amplifier Under Rear Deck
RIGHT FRONT SPEAKERS (+)	GRAY	At Bose Amplifier Under Rear Deck
RIGHT FRONT SPEAKERS (-)	YELLOW	At Bose Amplifier Under Rear Deck
LEFT REAR SPEAKER (+)	GREEN/YELLOW	At Bose Amplifier Under Rear Deck
LEFT REAR SPEAKER (-)	BLACK/YELLOW	At Bose Amplifier Under Rear Deck
RIGHT REAR SPEAKER (+)	BROWN	At Bose Amplifier Under Rear Deck
RIGHT REAR SPEAKER (-)	BLACK	At Bose Amplifier Under Rear Deck
LEFT SUBWOOFER (+)	BLUE/YELLOW	At Bose Amplifier Under Rear Deck
LEFT SUBWOOFER (-)	WHITE/GREEN	At Bose Amplifier Under Rear Deck
RIGHT SUBWOOFER (+)	BLUE/RED	At Bose Amplifier Under Rear Deck
RIGHT SUBWOOFER (+)	BLUE/WHITE	At Bose Amplifier Under Rear Deck

AUDIO SYSTEM NOTES

FRONT SPEAKERS	REAR SPEAKERS	AMP LOCATION	NOTES
5.25"	5.25", 6x9"		

STEREO INSTALLATION PARTS

BRAND	DASH KIT	WIRE HARNESS ADAPTER	ANTENNA ADAPTER
METRA	99-7604	70-7551	40-NI10
SCOSCHE	II1652	NN03B	NDAB

Notes: dash kit comes in different colors: Gun Metal Gray: II1652GMB, Pewter: II1652PB, Charcoal Gray: II1652CHB

Please verify all part numbers before ordering.

ALARM & REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE 1	RED/WHITE or WHITE/RED	Ignition Harness
STARTER WIRE 2	WHITE/GREEN	Ignition Harness
IGNITION WIRE 1	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	WHITE/BLACK	Ignition Harness
FACTRY ALARM ARM	Arms With Lock	
FACTRY ALARM DISARM	Disarms With Unlock	
DISARM NO UNLOCK	Single Pulse On The Unlock Wire Will Disarm The Alarm Without Unlocking The Doors	
TACHOMETER WIRE	Any Wire NOT BLACK Or WHITE/BLUE	At Ignition Coil
BRAKE WIRE (+)	LT.GREEN/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
POWER DOOR LOCK (-)	YELLOW	At Module Inside Driver's Door
NOTE: Test door lock wires while turning the key in the driver's door. Unlock requires a double pulse.		
POWER DOOR UNLOCK (-)	LIGHT BLUE	At Module Inside Driver's Door
NOTE: Extended triggers on the power door lock wires will operate the power windows.		
TRUNK RELEASE (-)	BLUE	Brown Connector At Body Control Module In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel Running Towards Rear Of Vehicle
ALL DOOR TRIGGER (-)		
LEFT FRONT DOOR TRIGGER (-)	YELLOW	At Body Control Module In Driver's Kick Panel
RIGHT FRONT DOOR TRIGGER (-)	PINK	At Body Control Module In Driver's Kick Panel
DOMESUPERVISION	Dome light comes on with unlock	
TRUNK TRIGGER (-)	RED/WHITE	White Connector At Body Control Module In Driver's Kick Panel
HOOD TRIGGER (-)	LT GREEN/BLACK	Pin Switch Under Hood

ALARM & REMOTE START INTERFACE MODULES

MODULE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AMPLIFIED AUDIO WIRING

WIRE	COLOR	LOCATION
RADIO 12V	YELLOW	Radio Harness
RADIO SWITCHED	LIGHT GREEN	Radio Harness
RADIO GROUND		Ground to chassis
ILLUMINATION (+)	RED/YELLOW	Radio Harness
POWER ANTENNA (+)	GREEN/WHITE	Radio Harness
AMP TURN ON	GREEN/YELLOW	Radio Harness
LEFT FRONT TO AMP (+)	WHITE	Radio Harness
LEFT FRONT TO AMP (-)	BLACK	Radio Harness
RIGHT FRONT TO AMP (+)	GREEN	Radio Harness
RIGHT FRONT TO AMP (-)	RED	Radio Harness
LEFT REAR TO AMP (+)	BROWN	Radio Harness
LEFT REAR TO AMP (-)	YELLOW	Radio Harness
RIGHT REAR TO AMP (+)	BLUE	Radio Harness
RIGHT REAR TO AMP (-)	PINK	Radio Harness
LEFT FRONT SPEAKERS (+)	GREEN	At Bose Amplifier Under Rear Deck
LEFT FRONT SPEAKERS (-)	RED	At Bose Amplifier Under Rear Deck
RIGHT FRONT SPEAKERS (+)	GRAY	At Bose Amplifier Under Rear Deck
RIGHT FRONT SPEAKERS (-)	YELLOW	At Bose Amplifier Under Rear Deck
LEFT REAR SPEAKER (+)	GREEN/YELLOW	At Bose Amplifier Under Rear Deck
LEFT REAR SPEAKER (-)	BLACK/YELLOW	At Bose Amplifier Under Rear Deck
RIGHT REAR SPEAKER (+)	BROWN	At Bose Amplifier Under Rear Deck
RIGHT REAR SPEAKER (-)	BLACK	At Bose Amplifier Under Rear Deck
LEFT SUBWOOFER (+)	BLUE/YELLOW	At Bose Amplifier Under Rear Deck
LEFT SUBWOOFER (-)	WHITE/GREEN	At Bose Amplifier Under Rear Deck
RIGHT SUBWOOFER (+)	BLUE/RED	At Bose Amplifier Under Rear Deck
RIGHT SUBWOOFER (+)	BLUE/WHITE	At Bose Amplifier Under Rear Deck

AUDIO SYSTEM NOTES

FRONT SPEAKERS	REAR SPEAKERS	AMP LOCATION	NOTES
5.25"	5.25", 6x9"		

STEREO INSTALLATION PARTS

BRAND	DASH KIT	WIRE HARNESS ADAPTER	ANTENNA ADAPTER
METRA	99-7604	70-7551	40-NI10
SCOSCHE	II1652	NN03B	NDAB

Notes: dash kit comes in different colors: Gun Metal Gray: II1652GMB, Pewter: II1652PB, Charcoal Gray: II1652CHB

Please verify all part numbers before ordering.

ALARM & REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE 1	RED/WHITE or WHITE/RED	Ignition Harness
STARTER WIRE 2	WHITE/GREEN	Ignition Harness
IGNITION WIRE 1	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	WHITE/BLACK	Ignition Harness
FACTRY ALARM ARM	Arms With Lock	
FACTRY ALARM DISARM	Disarms With Unlock	
DISARM NO UNLOCK	Single Pulse On The Unlock Wire Will Disarm The Alarm Without Unlocking The Doors	
TACHOMETER WIRE	Any Wire NOT BLACK Or WHITE/BLUE	At Ignition Coil
BRAKE WIRE (+)	LT.GREEN/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
POWER DOOR LOCK (-)	YELLOW	At Module Inside Driver's Door
NOTE: Test door lock wires while turning the key in the driver's door. Unlock requires a double pulse.		
POWER DOOR UNLOCK (-)	LIGHT BLUE	At Module Inside Driver's Door
NOTE: Extended triggers on the power door lock wires will operate the power windows.		
TRUNK RELEASE (-)	BLUE	Brown Connector At Body Control Module In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel Running Towards Rear Of Vehicle
ALL DOOR TRIGGER (-)		
LEFT FRONT DOOR TRIGGER (-)	YELLOW	At Body Control Module In Driver's Kick Panel
RIGHT FRONT DOOR TRIGGER (-)	PINK	At Body Control Module In Driver's Kick Panel
DOME SUPERVISION	Dome light comes on with unlock	
TRUNK TRIGGER (-)	RED/WHITE	White Connector At Body Control Module In Driver's Kick Panel
HOOD TRIGGER (-)	LT GREEN/BLACK	Pin Switch Under Hood

ALARM & REMOTE START INTERFACE MODULES

MODULE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AMPLIFIED AUDIO WIRING		
WIRE	COLOR	LOCATION
RADIO 12V	YELLOW	Radio Harness
RADIO SWITCHED	LIGHT GREEN	Radio Harness
RADIO GROUND		Ground to chassis
ILLUMINATION (+)	RED/YELLOW	Radio Harness
POWER ANTENNA (+)	GREEN/WHITE	Radio Harness
AMP TURN ON	GREEN/YELLOW	Radio Harness
LEFT FRONT TO AMP (+)	WHITE	Radio Harness
LEFT FRONT TO AMP (-)	BLACK	Radio Harness
RIGHT FRONT TO AMP (+)	GREEN	Radio Harness
RIGHT FRONT TO AMP (-)	RED	Radio Harness
LEFT REAR TO AMP (+)	BROWN	Radio Harness
LEFT REAR TO AMP (-)	YELLOW	Radio Harness
RIGHT REAR TO AMP (+)	BLUE	Radio Harness
RIGHT REAR TO AMP (-)	PINK	Radio Harness
LEFT FRONT SPEAKERS (+)	GREEN	At Bose Amplifier Under Rear Deck
LEFT FRONT SPEAKERS (-)	RED	At Bose Amplifier Under Rear Deck
RIGHT FRONT SPEAKERS (+)	GRAY	At Bose Amplifier Under Rear Deck
RIGHT FRONT SPEAKERS (-)	YELLOW	At Bose Amplifier Under Rear Deck
LEFT REAR SPEAKER (+)	GREEN/YELLOW	At Bose Amplifier Under Rear Deck
LEFT REAR SPEAKER (-)	BLACK/YELLOW	At Bose Amplifier Under Rear Deck
RIGHT REAR SPEAKER (+)	BROWN	At Bose Amplifier Under Rear Deck
RIGHT REAR SPEAKER (-)	BLACK	At Bose Amplifier Under Rear Deck
LEFT SUBWOOFER (+)	BLUE/YELLOW	At Bose Amplifier Under Rear Deck
LEFT SUBWOOFER (-)	WHITE/GREEN	At Bose Amplifier Under Rear Deck
RIGHT SUBWOOFER (+)	BLUE/RED	At Bose Amplifier Under Rear Deck
RIGHT SUBWOOFER (+)	BLUE/WHITE	At Bose Amplifier Under Rear Deck

AUDIO SYSTEM NOTES			
FRONT SPEAKERS	REAR SPEAKERS	AMP LOCATION	NOTES
6.5"	5.25", 6x9"		

STEREO INSTALLATION PARTS			
BRAND	DASH KIT	WIRE HARNESS ADAPTER	ANTENNA ADAPTER
METRA	99-7605	70-7551	40-NI10
SCOSCHE	II1650B	NN03B	NDAB

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM & REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE 1	RED/WHITE or WHITE/RED	Ignition Harness
STARTER WIRE 2	WHITE/GREEN	Ignition Harness
IGNITION WIRE 1	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	WHITE/BLACK	Ignition Harness
FACTRY ALARM ARM	Arms With Lock	
FACTRY ALARM DISARM	Disarms With Unlock	
DISARM NO UNLOCK	Single Pulse On The Unlock Wire Will Disarm The Alarm Without Unlocking The Doors	
TACHOMETER WIRE	Any Wire NOT BLACK Or WHITE/BLUE	At Ignition Coil
BRAKE WIRE (+)	LT.GREEN/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
POWER DOOR LOCK (-)	YELLOW	At Module Inside Driver's Door
NOTE: Test door lock wires while turning the key in the driver's door. Unlock requires a double pulse.		
POWER DOOR UNLOCK (-)	LIGHT BLUE	At Module Inside Driver's Door
NOTE: Extended triggers on the power door lock wires will operate the power windows.		
TRUNK RELEASE (-)	BLUE	Brown Connector At Body Control Module In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel Running Towards Rear Of Vehicle
ALL DOOR TRIGGER (-)		
LEFT FRONT DOOR TRIGGER (-)	YELLOW	At Body Control Module In Driver's Kick Panel
RIGHT FRONT DOOR TRIGGER (-)	PINK	At Body Control Module In Driver's Kick Panel
DOMESUPERVISION	Dome light comes on with unlock	
TRUNK TRIGGER (-)	RED/WHITE	White Connector At Body Control Module In Driver's Kick Panel
HOOD TRIGGER (-)	LT GREEN/BLACK	Pin Switch Under Hood

ALARM & REMOTE START INTERFACE MODULES

MODULE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AMPLIFIED AUDIO WIRING

WIRE	COLOR	LOCATION
RADIO 12V	YELLOW	Radio Harness
RADIO SWITCHED	LIGHT GREEN	Radio Harness
RADIO GROUND		Ground to chassis
ILLUMINATION (+)	RED/YELLOW	Radio Harness
POWER ANTENNA (+)	GREEN/WHITE	Radio Harness
AMP TURN ON	GREEN/YELLOW	Radio Harness
LEFT FRONT TO AMP (+)	WHITE	Radio Harness
LEFT FRONT TO AMP (-)	BLACK	Radio Harness
RIGHT FRONT TO AMP (+)	GREEN	Radio Harness
RIGHT FRONT TO AMP (-)	RED	Radio Harness
LEFT REAR TO AMP (+)	BROWN	Radio Harness
LEFT REAR TO AMP (-)	YELLOW	Radio Harness
RIGHT REAR TO AMP (+)	BLUE	Radio Harness
RIGHT REAR TO AMP (-)	PINK	Radio Harness
LEFT FRONT SPEAKERS (+)	GREEN	At Bose Amplifier Under Rear Deck
LEFT FRONT SPEAKERS (-)	RED	At Bose Amplifier Under Rear Deck
RIGHT FRONT SPEAKERS (+)	GRAY	At Bose Amplifier Under Rear Deck
RIGHT FRONT SPEAKERS (-)	YELLOW	At Bose Amplifier Under Rear Deck
LEFT REAR SPEAKER (+)	GREEN/YELLOW	At Bose Amplifier Under Rear Deck
LEFT REAR SPEAKER (-)	BLACK/YELLOW	At Bose Amplifier Under Rear Deck
RIGHT REAR SPEAKER (+)	BROWN	At Bose Amplifier Under Rear Deck
RIGHT REAR SPEAKER (-)	BLACK	At Bose Amplifier Under Rear Deck
LEFT SUBWOOFER (+)	BLUE/YELLOW	At Bose Amplifier Under Rear Deck
LEFT SUBWOOFER (-)	WHITE/GREEN	At Bose Amplifier Under Rear Deck
RIGHT SUBWOOFER (+)	BLUE/RED	At Bose Amplifier Under Rear Deck
RIGHT SUBWOOFER (+)	BLUE/WHITE	At Bose Amplifier Under Rear Deck

AUDIO SYSTEM NOTES

FRONT SPEAKERS	REAR SPEAKERS	AMP LOCATION	NOTES
6.5"	5.25", 6x9"		

STEREO INSTALLATION PARTS

BRAND	DASH KIT	WIRE HARNESS ADAPTER	ANTENNA ADAPTER
METRA	99-7605	70-7551	40-NI10
SCOSCHE	II1650B	NN03B	NDAB

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE 1	RED/WHITE or WHITE/RED	Ignition Harness
STARTER WIRE 2	WHITE/GREEN	Ignition Harness
IGNITION WIRE 1	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	WHITE/BLACK	Ignition Harness
FACTRY ALARM ARM	Arms With Lock	
FACTRY ALARM DISARM	Disarms With Unlock	
DISARM NO UNLOCK	Single Pulse On The Unlock Wire Will Disarm The Alarm Without Unlocking The Doors	
TACHOMETER WIRE	Any Wire NOT BLACK Or WHITE/BLUE	At Ignition Coil
BRAKE WIRE (+)	LT.GREEN/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
POWER DOOR LOCK (-)	YELLOW	At Module Inside Driver's Door
Notes: Test door lock wires while turning the key in the driver's door. Unlock requires a double pulse.		
POWER DOOR UNLOCK (-)	LIGHT BLUE	At Module Inside Driver's Door
Notes: Extended triggers on the power door lock wires will operate the power windows.		
TRUNK RELEASE (-)	BLUE	Brown Connector At Body Control Module In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel Running Towards Rear Of Vehicle
ALL DOOR TRIGGER (-)		
LEFT FRONT DOOR TRIGGER (-)	YELLOW	At Body Control Module In Driver's Kick Panel
RIGHT FRONT DOOR TRIGGER (-)	PINK	At Body Control Module In Driver's Kick Panel
DOMESUPERVISION	Dome light comes on with unlock	
TRUNK TRIGGER (-)	RED/WHITE	White Connector At Body Control Module In Driver's Kick Panel
HOOD TRIGGER (-)	LT GREEN/BLACK	Pin Switch Under Hood

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
12V SWITCHED	LT.GREEN	Radio Harness	
RADIO GROUND	Grounds to radio bracket		
AMP TURN ON (+)	GREEN/YELLOW	At Radio Harness	
LEFT FRONT SPEAKER (+)	WHITE	At Factory Amplifier Located In Trunk on Driver Side	
LEFT FRONT SPEAKER (-)	BLACK	At Factory Amplifier Located In Trunk on Driver Side	
RIGHT FRONT SPEAKER (+)	GREEN	At Factory Amplifier Located In Trunk on Driver Side	
RIGHT FRONT SPEAKER (-)	RED	At Factory Amplifier Located In Trunk on Driver Side	
LEFT REAR SPEAKER (+)	BROWN	At Factory Amplifier Located In Trunk on Driver Side	
LEFT REAR SPEAKER (-)	YELLOW	At Factory Amplifier Located In Trunk on Driver Side	
RIGHT REAR SPEAKER (+)	BLUE	At Factory Amplifier Located In Trunk on Driver Side	
RIGHT REAR SPEAKER (-)	PINK	At Factory Amplifier Located In Trunk on Driver Side	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5.25", 6x9"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7605, SCOSCHE II1650B		METRA 70-7551, SCOSCHE NN03B	METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.