

Vehicle Wiring Information
for the
2002 Honda Insight

ITEM	WIRE COLOR	POL	WIRE LOCATION
	12V white	+	ignition harness
	STARTER black/white	+	ignition harness
	IGNITION black/yellow	+	ignition harness
	ACCESSORY yellow	+	ignition harness
	SECOND ACCESSORY white/black *1	+	ignition harness
	POWER LOCK white/blue	-	keyless door lock unit *2
	POWER UNLOCK white/green	-	keyless door lock unit *2
	LOCK MOTOR yellow/black		keyless door lock unit *2
	UNLOCK MOTOR yellow/green		keyless door lock unit *2
	DISARM DEFEAT yellow		keyless door lock unit *2
	PARKING LIGHTS + red/white		keyless door lock unit *2
	PARKING LIGHTS - blue		headlight switch or *2
	HEADLIGHTS blue/red	-	headlight switch
	DOOR TRIGGER lt. green/red	-	keyless door lock unit *2
	DOME SUPERVISION comes on with unlock		
	TRUNK/HATCH PIN common with doors		
	TRNK/HATCH RELEASE blue	+	release switch
	FCTRY ALARM ARM factory remote only		
	FCTRY ALRM DISARM factory remote only		
	TACHOMETER blue		tach test connector *3
	SPEED SENSE blue/white		ECM *4
	BRAKE WIRE green/white	+	brake pedal switch
	HORN TRIGGER orange	-	steering column or *2
	WIPERS blue (L), blu/yel (H) -		steering column
	LF WINDOW UP/DN red/blk - red/yel	A	window switch on dash
	RF WINDOW UP/DN blu/red - blu/wht	A	window switch on dash
	RADIO 12V white	+	radio
	RADIO GROUND black	-	radio
	RADIO SWITCH yellow/red	+	radio
	RADIO ILLUMINATE red/black	+	radio
	POWER ANTENNA white/green	+	radio
	LF SPEAKER black - lt. green		radio
	RF SPEAKER grn/yel - gry/red		radio
	LR SPEAKER blu/wht - blu/blk		radio
	RR SPEAKER pink - blu/yel		radio

Notes:

NOTE: This vehicle has an immobilizer system that needs to be bypassed when adding remote start. Use DEI part number 555U. *1 Not required for remote start. *2 The keyless door lock control unit is behind the coin box on the driver side dash. *3 The tach test connector is above the brake master cylinder. *4 The ECM is on the passenger side floor below the glove box. The VSS wire is in the blue 31 pin connector, pin 5.

Vehicle Wiring Information

for the

2001 Honda Insight

ITEM	WIRE COLOR	POL	WIRE LOCATION
	12V white	+	ignition harness
STARTER	black/white	+	ignition harness
IGNITION	black/yellow	+	ignition harness
ACCESSORY	yellow	+	ignition harness
SECOND ACCESSORY	white/black *1	+	ignition harness
POWER LOCK	white/blue	-	keyless door lock unit *2
POWER UNLOCK	white/green	-	keyless door lock unit *2
LOCK MOTOR	yellow/black		keyless door lock unit *2
UNLOCK MOTOR	yellow/green		keyless door lock unit *2
DISARM DEFEAT	yellow		keyless door lock unit *2
PARKING LIGHTS +	red/white		keyless door lock unit *2
PARKING LIGHTS -	blue		headlight switch or *2
HEADLIGHTS	blue/red	-	headlight switch
DOOR TRIGGER	lt. green/red	-	keyless door lock unit *2
DOME SUPERVISION	comes on with unlock		
TRUNK/HATCH PIN	common with doors		
TRNK/HTCH RELEASE	blue	+	release switch
FCTRY ALARM ARM	factory remote only		
FCTRY ALRM DISARM	factory remote only		
TACHOMETER	blue		tach test connector *3
SPEED SENSE	blue/white		ECM *4
BRAKE WIRE	green/white	+	brake pedal switch
HORN TRIGGER	orange	-	steering column or *2
WIPERS	blue (L), blu/yel (H)	-	steering column
LF WINDOW UP/DN	red/blk - red/yel	A	window switch on dash
RF WINDOW UP/DN	blu/red - blu/wht	A	window switch on dash
RADIO 12V	white	+	radio
RADIO GROUND	black	-	radio
RADIO SWITCH	yellow/red	+	radio
RADIO ILLUMINATE	red/black	+	radio
POWER ANTENNA	white/green	+	radio
LF SPEAKER	black - lt. green		radio
RF SPEAKER	grn/yel - gry/red		radio
LR SPEAKER	blu/wht - blu/blk		radio
RR SPEAKER	pink - blu/yel		radio

Notes:

NOTE: This vehicle has an immobilizer system that needs to be bypassed when adding remote start. Use DEI part number 555U. *1 Not required for remote start. *2 The keyless door lock control unit is behind the coin box on the driver side dash. *3 The tach test connector is above the brake master cylinder. *4 The ECM is on the passenger side floor below the glove box. The VSS wire is in the blue 31 pin connector, pin 5.

Vehicle Wiring Information
for the
2000 Honda Insight

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	white	+	ignition harness
STARTER	black/white	+	ignition harness
IGNITION	black/yellow	+	ignition harness
ACCESSORY	yellow	+	ignition harness
SECOND ACCESSORY	white/black *1	+	ignition harness
POWER LOCK	white/blue	-	keyless door lock unit *2
POWER UNLOCK	white/green	-	keyless door lock unit *2
LOCK MOTOR	yellow/black		keyless door lock unit *2
UNLOCK MOTOR	yellow/green		keyless door lock unit *2
DISARM DEFEAT	yellow		keyless door lock unit *2
PARKING LIGHTS +	red/white		keyless door lock unit *2
PARKING LIGHTS -	blue		headlight switch or *2
HEADLIGHTS	blue/red	-	headlight switch
DOOR TRIGGER	lt. green/red	-	keyless door lock unit *2
DOME SUPERVISION	comes on with unlock		
TRUNK/HATCH PIN	common with doors		
TRNK/HATCH RELEASE	blue	+	release switch
FACTRY ALARM ARM	factory remote only		
FACTRY ALRM DISARM	factory remote only		
TACHOMETER	blue		tach test connector *3
SPEED SENSE	blue/white		ECM *4
BRAKE WIRE	green/white	+	brake pedal switch
HORN TRIGGER	orange	-	steering column or *2
WIPERS	blue (L), blu/yel (H)	-	steering column
LF WINDOW UP/DN	red/blk - red/yel	A	window switch on dash
RF WINDOW UP/DN	blu/red - blu/wht	A	window switch on dash
RADIO 12V	white	+	radio
RADIO GROUND	black	-	radio
RADIO SWITCH	yellow/red	+	radio
RADIO ILLUMINATE	red/black	+	radio
POWER ANTENNA	white/green	+	radio
LF SPEAKER	black - lt. green		radio
RF SPEAKER	grn/yel - gry/red		radio
LR SPEAKER	blu/wht - blu/blk		radio
RR SPEAKER	pink - blu/yel		radio

Notes:

NOTE: This vehicle has an immobilizer system that needs to be bypassed when adding remote start. Use DEI part number 555U. *1 Not required for remote start. *2 The keyless door lock control unit is behind the coin box on the driver side dash. *3 The tach test connector is above the brake master cylinder. *4 The ECM is on the passenger side floor below the glove box. The VSS wire is in the blue 31 pin connector, pin 5.