

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLUE/RED or RED	Ignition Harness
STARTER WIRE	BLUE	Ignition Harness
SECOND STARTER WIRE	PINK	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
ACCESSORY WIRE	WHITE	Ignition Harness
POWER DOOR LOCK (-)	PINK	At Module In Driver's Door
POWER DOOR UNLOCK (-)	ORANGE	At Module In Driver's Door
Notes: Test door lock wires while turning the key in the driver's door		
PARKING LIGHTS (+)	WHITE	In White Connector In Driver's Kick Panel
DRIVER DOOR TRIGGER WIRE (-)	WHITE	At Body Control Module In Driver's Kick Panel
PASSENGER FRONT DOOR TRIGGER	BLACK	At Body Control Module In Driver's Kick Panel
DRIVER REAR DOOR TRIGGER WIRE (-)	PINK	At Body Control Module In Driver's Kick Panel
PASSENGER REAR DOOR TRIGGER WI	PINK/BLUE	At Body Control Module IN Driver's Kick Panel
DOMELIGHT SUPERVISION (-)	PURPLE/WHITE	In Black Connector At Body Control Module
TRUNK TRIGGER (-)	BLUE	At Body Control Module In Driver's Kick Panel
HOOD TRIGGER (-)	LIGHT GREEN	At Factory Hood Pin
TRUNK RELEASE (+)	ORANGE OR LT. GREEN	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	Any wire that is NOT WHITE or BLACK	At Ignition Coil
BRAKE WIRE (+)	PINK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK or LIGHT/BLUE	At Steering Column
LEFT FRONT WINDOW UP	Extended triggers on the door lock wires will operate the power windows	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/BLUE	Radio Harness	
RADIO SWITCHED	LIGHT GREEN/RED	Radio Harness	
RADIO GROUND	CHASSIS		
ILLUMINATION (+)	RED/BLUE	Radio Harness	
POWER ANTENNA (+)	RED/WHITE	Radio Harness	
AMP TURN ON (+)	GREEN/WHITE	Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4", 6.5"	4", 6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
None available	None available		None available
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLUE/RED or RED	Ignition Harness
STARTER WIRE	BLUE	Ignition Harness
SECOND STARTER WIRE	PINK	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
ACCESSORY WIRE	WHITE	Ignition Harness
POWER DOOR LOCK (-)	PINK	At Module In Driver's Door
POWER DOOR UNLOCK (-)	ORANGE	At Module In Driver's Door
Notes: Test door lock wires while turning the key in the driver's door		
PARKING LIGHTS (+)	WHITE	In White Connector In Driver's Kick Panel
DRIVER DOOR TRIGGER WIRE (-)	WHITE	At Body Control Module In Driver's Kick Panel
PASSENGER FRONT DOOR TRIGGER	BLACK	At Body Control Module In Driver's Kick Panel
DRIVER REAR DOOR TRIGGER WIRE (-)	PINK	At Body Control Module In Driver's Kick Panel
PASSENGER REAR DOOR TRIGGER WI	PINK/BLUE	At Body Control Module IN Driver's Kick Panel
DOMELIGHT SUPERVISION (-)	PURPLE/WHITE	In Black Connector At Body Control Module
TRUNK TRIGGER (-)	BLUE	At Body Control Module In Driver's Kick Panel
HOOD TRIGGER (-)	LIGHT GREEN	At Factory Hood Pin
TRUNK RELEASE (+)	ORANGE OR LT. GREEN	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	Any wire that is NOT WHITE or BLACK	At Ignition Coil
BRAKE WIRE (+)	PINK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK or LIGHT/BLUE	At Steering Column
LEFT FRONT WINDOW UP	Extended triggers on the door lock wires will operate the power windows	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/BLUE	Radio Harness	
RADIO SWITCHED	LIGHT GREEN/RED	Radio Harness	
RADIO GROUND	CHASSIS		
ILLUMINATION (+)	RED/BLUE	Radio Harness	
POWER ANTENNA (+)	RED/WHITE	Radio Harness	
AMP TURN ON (+)	GREEN/WHITE	Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4", 6.5"	4", 6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS	
None available	None available	None available	
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLUE/RED or RED	Ignition Harness
STARTER WIRE	BLUE	Ignition Harness
SECOND STARTER WIRE	PINK	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
ACCESSORY WIRE	WHITE	Ignition Harness
POWER DOOR LOCK (-)	PINK	At Module In Driver's Door
POWER DOOR UNLOCK (-)	ORANGE	At Module In Driver's Door
Notes: Test door lock wires while turning the key in the driver's door		
PARKING LIGHTS (+)	WHITE	In White Connector In Driver's Kick Panel
DRIVER DOOR TRIGGER WIRE (-)	WHITE	At Body Control Module In Driver's Kick Panel
PASSENGER FRONT DOOR TRIGGER	BLACK	At Body Control Module In Driver's Kick Panel
DRIVER REAR DOOR TRIGGER WIRE (-)	PINK	At Body Control Module In Driver's Kick Panel
PASSENGER REAR DOOR TRIGGER WI	PINK/BLUE	At Body Control Module IN Driver's Kick Panel
DOMELIGHT SUPERVISION (-)	PURPLE/WHITE	In Black Connector At Body Control Module
TRUNK TRIGGER (-)	BLUE	At Body Control Module In Driver's Kick Panel
HOOD TRIGGER (-)	LIGHT GREEN	At Factory Hood Pin
TRUNK RELEASE (+)	ORANGE OR LT. GREEN	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	Any wire that is NOT WHITE or BLACK	At Ignition Coil
BRAKE WIRE (+)	PINK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK or LIGHT/BLUE	At Steering Column
LEFT FRONT WINDOW UP	Extended triggers on the door lock wires will operate the power windows	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/BLUE	Radio Harness	
RADIO SWITCHED	LIGHT GREEN/RED	Radio Harness	
RADIO GROUND	CHASSIS		
ILLUMINATION (+)	RED/BLUE	Radio Harness	
POWER ANTENNA (+)	RED/WHITE	Radio Harness	
AMP TURN ON (+)	GREEN/WHITE	Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4", 6.5"	4", 6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
None available	None available		None available
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.