

# **TRIPLE S** *Customs*

## **LEXUS LX450 1996-1997 VEHICLE WIRING**

WIRING INFORMATION: 1996 Lexus LX450

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT	BLACK or WHITE/RED	Ignition Harness
STARTER	BLACK/WHITE	Ignition Harness
IGNITION	BLACK/YELLOW	Ignition Harness
SECOND IGNITION	BLACK/GREEN OR BLACK/RED	Ignition Harness
ACCESSORY	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	BLUE/BLACK	Drivers Kick Panel In Harness Coming From Door
POWER DOORUNLOCK (-)	BLUE/YELLOW AND BLUE/ORANGE	Drivers Kick Panel In Harness Coming From Door
There are two door unlock wires must be used and diode isolated.		
PARKING LIGHTS (+)	GREEN	Drivers Kick
HEADLIGHTS (-)	RED-GREEN	Steering Column
DOOR TRIGGER (-)	RED/WHITE	Back Of Instrument Cluster
For door trigger, may also be found RED/BLUE or WHITE in top of the fuse box in a harness from dome light.		
DOMELIGHT SUPERVISION (-)	RED/BLUE	Harness At Top of Fuse Box
REAR HATCH TRIGGER	TIED WITH DOOR	
TACHOMETER WIRE	BLACK	Igniter Or Test Connector Near Wiper Motor On Passenger Side of Engine Bay.
BRAKE WIRE (+)	GREEN/WHITE	Brake Switch
HORN TRIGGER (-)	GREEN/BLUE	Steering Column
LEFT FRONT WINDOW UP	BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLACK/GREEN	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLACK/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLACK/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1997 Lexus LX450

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT	BLACK or WHITE/RED	Ignition Harness
STARTER	BLACK/WHITE	Ignition Harness
IGNITION	BLACK/YELLOW	Ignition Harness
SECOND IGNITION	BLACK/GREEN OR BLACK/RED	Ignition Harness
ACCESSORY	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	BLUE/BLACK	Drivers Kick Panel In Harness Coming From Door
POWER DOORUNLOCK (-)	BLUE/YELLOW AND BLUE/ORANGE	Drivers Kick Panel In Harness Coming From Door
There are two door unlock wires must be used and diode isolated.		
PARKING LIGHTS (+)	GREEN	Drivers Kick
HEADLIGHTS (-)	RED-GREEN	Steering Column
DOOR TRIGGER (-)	RED/WHITE	Back Of Instrument Cluster
For door trigger, may also be found RED/BLUE or WHITE in top of the fuse box in a harness from dome light.		
DOMELIGHT SUPERVISION (-)	RED/BLUE	Harness At Top of Fuse Box
REAR HATCH TRIGGER	TIED WITH DOOR	
TACHOMETER WIRE	BLACK	Igniter Or Test Connector Near Wiper Motor On Passenger Side of Engine Bay.
BRAKE WIRE (+)	GREEN/WHITE	Brake Switch
HORN TRIGGER (-)	GREEN/BLUE	Steering Column
LEFT FRONT WINDOW UP	BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLACK/GREEN	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLACK/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLACK/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/BLUE	Harness In Driver's Kick From Driver Door