

TRIPLE S *Customs*

**PORSCHE 944 1986-1992
VEHICLE WIRING**

WIRING INFORMATION: 1986 Porsche 944

WIRE	WIRE COLOR	WIRE LOCATION
12V	RED or RED/WHITE	Fuse Box
STARTER	RED/BLACK	Fuse Box
IGNITION	BLACK	Fuse Box
SECOND IGNITION	BLACK/YELLOW	Fuse Box
ACCESSORY	RED/BLACK plug	Fuse Box
POWER LOCK (-)	BROWN/WHITE	At Module Under Steering Column
POWER UNLOCK (-)	BROWN/RED	At Module under Steering Column
PARKING LIGHTS (+)	GRAY/RED AND GRAY/BLACK	At Light Switch Or Fuse Box
HEADLIGHTS (+)	WHITE/BLACK	At Light Switch
DOOR TRIGGER (-)	BROWN/YELLOW	Passenger Door Pin
REAR HATCH TRIGGER	TIED WITH DOOR	
REAR HATCH RELEASE (5-wire)	RED/WHITE	At Release Switch Or Driver Kick Panel
TACHOMETER WIRE	GREEN or GREEN/BLACK	Ignition Coil
BRAKE WIRE (+)	RED/WHITE	Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	At Relay In Fuse Box
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

NOTE:

WIRING INFORMATION: 1987 Porsche 944

WIRE	WIRE COLOR	WIRE LOCATION
12V	RED or RED/WHITE	Fuse Box
STARTER	RED/BLACK	Fuse Box
IGNITION	BLACK	Fuse Box
SECOND IGNITION	BLACK/YELLOW	Fuse Box
ACCESSORY	RED/BLACK plug	Fuse Box
POWER LOCK (-)	BROWN/WHITE	At Module Under Steering Column
POWER UNLOCK (-)	BROWN/RED	At Module under Steering Column
PARKING LIGHTS (+)	GRAY/RED AND GRAY/BLACK	At Light Switch Or Fuse Box
HEADLIGHTS (+)	WHITE/BLACK	At Light Switch
DOOR TRIGGER (-)	BROWN/YELLOW	Passenger Door Pin
REAR HATCH TRIGGER	TIED WITH DOOR	
REAR HATCH RELEASE (5-wire)	RED/WHITE	At Release Switch Or Driver Kick Panel
TACHOMETER WIRE	GREEN or GREEN/BLACK	Ignition Coil
BRAKE WIRE (+)	RED/WHITE	Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	At Relay In Fuse Box
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1988 Porsche 944

WIRE	WIRE COLOR	WIRE LOCATION
12V	RED or RED/WHITE	Fuse Box
STARTER	RED/BLACK	Fuse Box
IGNITION	BLACK	Fuse Box
SECOND IGNITION	BLACK/YELLOW	Fuse Box
ACCESSORY	RED/BLACK plug	Fuse Box
POWER LOCK (-)	BROWN/WHITE	At Module Under Steering Column
POWER UNLOCK (-)	BROWN/RED	At Module under Steering Column
PARKING LIGHTS (+)	GRAY/RED AND GRAY/BLACK	At Light Switch Or Fuse Box
HEADLIGHTS (+)	WHITE/BLACK	At Light Switch
DOOR TRIGGER (-)	BROWN/YELLOW	Passenger Door Pin
REAR HATCH TRIGGER	TIED WITH DOOR	
REAR HATCH RELEASE (5-wire)	RED/WHITE	At Release Switch Or Driver Kick Panel
TACHOMETER WIRE	GREEN or GREEN/BLACK	Ignition Coil
BRAKE WIRE (+)	RED/WHITE	Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	At Relay In Fuse Box
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1989 Porsche 944

WIRE	WIRE COLOR	WIRE LOCATION
12V	RED or RED/WHITE	Underside Fuse Box
STARTER	RED/BLACK	Underside Fuse Box
IGNITION	BLACK	Underside Fuse Box
SECOND IGNITION	BLACK/YELLOW	Underside Fuse Box
ACCESSORY	RED/BLACK	Underside Fuse Box
POWER LOCK (-)	BROWN/WHITE	Relays At Steering Column Or Factory Anti-Theft Module
POWER UNLOCK (-)	BROWN/RED	Relays At Steering Column Or Factory Anti-Theft Module
PARKING LIGHTS (+)	GRAY/RED, GRAY/BLACK	At Light Switch
HEADLIGHTS (+)	WHITE/BLACK	At Light Switch
DOOR TRIGGER (-)	BROWN/YELLOW	Right Door Pin Or Factory Anti-Theft Module
REAR HATCH TRIGGER	TIED WITH DOOR	
HOOD TRIGGER (-)	BROWN/BLACK	Anti-Theft Module
REAR HATCH RELEASE (5-wire)	RED/WHITE	Release Switch Or Driver Kick Panel
FCTRY ALARM ARM	ARMS WITH LOCK	
FCTRY ALRM DISARM	DISARMS WITH UNLOCK	
TACHOMETER WIRE	GREEN Or GREEN/BLACK	Ignition Coil
BRAKE WIRE (+)	BLACK/GREEN	Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	At Relay In Fuse Box
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch
<ul style="list-style-type: none"> The factory anti-theft module is located below passenger side floorboard. Door trigger and trunk trigger can also be found independently at the theft module. BROWN/GREEN is the (-) Door Trigger, and BLACK is the (-) Rear Hatch Trigger. Use both and diode isolate. 		

WIRING INFORMATION: 1990 Porsche 944

WIRE	WIRE COLOR	WIRE LOCATION
12V	RED or RED/WHITE	Underside Fuse Box
STARTER	RED/BLACK	Underside Fuse Box
IGNITION	BLACK	Underside Fuse Box
SECOND IGNITION	BLACK/YELLOW	Underside Fuse Box
ACCESSORY	RED/BLACK	Underside Fuse Box
POWER LOCK (-)	BROWN/WHITE	Relays At Steering Column Or Factory Anti-Theft Module
POWER UNLOCK (-)	BROWN/RED	Relays At Steering Column Or Factory Anti-Theft Module
PARKING LIGHTS (+)	GRAY/RED, GRAY/BLACK	At Light Switch
HEADLIGHTS (+)	WHITE/BLACK	At Light Switch
DOOR TRIGGER (-)	BROWN/YELLOW	Right Door Pin Or Factory Anti-Theft Module
REAR HATCH TRIGGER	TIED WITH DOOR	
HOOD TRIGGER (-)	BROWN/BLACK	Anti-Theft Module
REAR HATCH RELEASE (5-wire)	RED/WHITE	Release Switch Or Driver Kick Panel
FCTRY ALARM ARM	ARMS WITH LOCK	
FCTRY ALRM DISARM	DISARMS WITH UNLOCK	
TACHOMETER WIRE	GREEN Or GREEN/BLACK	Ignition Coil
BRAKE WIRE (+)	BLACK/GREEN	Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	At Relay In Fuse Box
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch
<ul style="list-style-type: none"> The factory anti-theft module is located below passenger side floorboard. Door trigger and trunk trigger can also be found independently at the theft module. BROWN/GREEN is the (-) Door Trigger, and BLACK is the (-) Rear Hatch Trigger. Use both and diode isolate. 		

WIRING INFORMATION: 1991 Porsche 944

WIRE	WIRE COLOR	WIRE LOCATION
12V	RED or RED/WHITE	Underside Fuse Box
STARTER	RED/BLACK	Underside Fuse Box
IGNITION	BLACK	Underside Fuse Box
SECOND IGNITION	BLACK/YELLOW	Underside Fuse Box
ACCESSORY	RED/BLACK	Underside Fuse Box
POWER LOCK (-)	BROWN/WHITE	Relays At Steering Column Or Factory Anti-Theft Module
POWER UNLOCK (-)	BROWN/RED	Relays At Steering Column Or Factory Anti-Theft Module
PARKING LIGHTS (+)	GRAY/RED, GRAY/BLACK	At Light Switch
HEADLIGHTS (+)	WHITE/BLACK	At Light Switch
DOOR TRIGGER (-)	BROWN/YELLOW	Right Door Pin Or Factory Anti-Theft Module
REAR HATCH TRIGGER	TIED WITH DOOR	
HOOD TRIGGER (-)	BROWN/BLACK	Anti-Theft Module
REAR HATCH RELEASE (5-wire)	RED/WHITE	Release Switch Or Driver Kick Panel
FCTRY ALARM ARM	ARMS WITH LOCK	
FCTRY ALRM DISARM	DISARMS WITH UNLOCK	
TACHOMETER WIRE	GREEN Or GREEN/BLACK	Ignition Coil
BRAKE WIRE (+)	BLACK/GREEN	Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	At Relay In Fuse Box
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch
<ul style="list-style-type: none"> The factory anti-theft module is located below passenger side floorboard. Door trigger and trunk trigger can also be found independently at the theft module. BROWN/GREEN is the (-) Door Trigger, and BLACK is the (-) Rear Hatch Trigger. Use both and diode isolate. 		

WIRING INFORMATION: 1992 Porsche 944

WIRE	WIRE COLOR	WIRE LOCATION
12V	RED or RED/WHITE	Underside Fuse Box
STARTER	RED/BLACK	Underside Fuse Box
IGNITION	BLACK	Underside Fuse Box
SECOND IGNITION	BLACK/YELLOW	Underside Fuse Box
ACCESSORY	RED/BLACK	Underside Fuse Box
POWER LOCK (-)	BROWN/WHITE	Relays At Steering Column Or Factory Anti-Theft Module
POWER UNLOCK (-)	BROWN/RED	Relays At Steering Column Or Factory Anti-Theft Module
PARKING LIGHTS (+)	GRAY/RED, GRAY/BLACK	At Light Switch
HEADLIGHTS (+)	WHITE/BLACK	At Light Switch
DOOR TRIGGER (-)	BROWN/YELLOW	Right Door Pin Or Factory Anti-Theft Module
REAR HATCH TRIGGER	TIED WITH DOOR	
HOOD TRIGGER (-)	BROWN/BLACK	Anti-Theft Module
REAR HATCH RELEASE (5-wire)	RED/WHITE	Release Switch Or Driver Kick Panel
FCTRY ALARM ARM	ARMS WITH LOCK	
FCTRY ALRM DISARM	DISARMS WITH UNLOCK	
TACHOMETER WIRE	GREEN Or GREEN/BLACK	Ignition Coil
BRAKE WIRE (+)	BLACK/GREEN	Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	At Relay In Fuse Box
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch
<ul style="list-style-type: none"> The factory anti-theft module is located below passenger side floorboard. Door trigger and trunk trigger can also be found independently at the theft module. BROWN/GREEN is the (-) Door Trigger, and BLACK is the (-) Rear Hatch Trigger. Use both and diode isolate. 		