

TRIPLE S *Customs*

SUBARU FORESTER 1998-2006 VEHICLE WIRING

WIRING INFORMATION 1998 Subaru Forester

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	BLACK/WHITE to WHITE	Ignition Harness
12V IGNITION WIRE	BLACK to GREEN	Ignition Harness
12V ACCESSORY WIRE	BLACK/BLUE to YELLOW	Ignition Harness
STARTER WIRE	BLACK/YELLOW to WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	RED/WHITE	At Door Lock Module Above Fuse Box
POWER DOOR UNLOCK (-)	YELLOW/RED	At Door Lock Module Above Fuse Box
PARKING LIGHTS (+)	ORANGE	Harness At Steering Column
DOOR TRIGGER (-)	YELLOW	Blue Connector At Steering Column
TRUNK TRIGGER (-)	Tied In With Doors	
TACHOMETER WIRE	BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	BLUE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	GREEN/YELLOW	At Window Switch In Driver's Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	At Window Switch In Driver's Door
RIGHT REAR WINDOW UP	BLUE/WHITE	At Window Switch In Driver's Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	At Window Switch In Driver's Door

WIRING INFORMATION 1999 Subaru Forester

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	BLACK/WHITE to WHITE	Ignition Harness
12V IGNITION WIRE	BLACK to GREEN	Ignition Harness
12V ACCESSORY WIRE	BLACK/BLUE to YELLOW	Ignition Harness
STARTER WIRE	BLACK/YELLOW to WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	RED/WHITE	At Door Lock Module Above Fuse Box
POWER DOOR UNLOCK (-)	YELLOW/RED	At Door Lock Module Above Fuse Box
PARKING LIGHTS (+)	ORANGE	Harness At Steering Column
DOOR TRIGGER (-)	YELLOW	Blue Connector At Steering Column
TRUNK TRIGGER (-)	Tied In With Doors	
TACHOMETER WIRE	BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	BLUE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	GREEN/YELLOW	At Window Switch In Driver's Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	At Window Switch In Driver's Door
RIGHT REAR WINDOW UP	BLUE/WHITE	At Window Switch In Driver's Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	At Window Switch In Driver's Door

WIRING INFORMATION 2000 Subaru Forester

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	RED/WHITE	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
POWER DOOR UNLOCK (-)	YELLOW/RED	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	YELLOW	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
TRUNK TRIGGER (-)	Tied In With Doors	
FACTORY ALARM ARM	Arms with factory remote only	
FACTORY ALARM DISARM	Disarms with factory remote only	
TACHOMETER	BLUE or RED/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	BLUE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	GREEN/YELLOW	At Window Switch In Driver's Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	At Window Switch In Driver's Door
RIGHT REAR WINDOW UP	BLUE/WHITE	At Window Switch In Driver's Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	At Window Switch In Driver's Door

WIRING INFORMATION 2001 Subaru Forester

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	RED/WHITE	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
POWER DOOR UNLOCK (-)	YELLOW/RED	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	YELLOW	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
TRUNK TRIGGER (-)	Tied In With Doors	
FACTORY ALARM ARM	Arms with factory remote only	
FACTORY ALARM DISARM	Disarms with factory remote only	
TACHOMETER	BLUE or RED/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	BLUE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	GREEN/YELLOW	At Window Switch In Driver's Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	At Window Switch In Driver's Door
RIGHT REAR WINDOW UP	BLUE/WHITE	At Window Switch In Driver's Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	At Window Switch In Driver's Door

WIRING INFORMATION 2002 Subaru Forester

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	RED/WHITE	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
POWER DOOR UNLOCK (-)	YELLOW/RED	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	YELLOW	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
TRUNK TRIGGER (-)	Tied In With Doors	
FACTORY ALARM ARM	Arms with factory remote only	
FACTORY ALARM DISARM	Disarms with factory remote only	
TACHOMETER	BLUE or RED/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	BLUE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	GREEN/YELLOW	At Window Switch In Driver's Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	At Window Switch In Driver's Door
RIGHT REAR WINDOW UP	BLUE/WHITE	At Window Switch In Driver's Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	At Window Switch In Driver's Door

WIRING INFORMATION 2003 Subaru Forester

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	RED/WHITE	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
POWER DOOR UNLOCK (-)	YELLOW/RED	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	YELLOW	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
TRUNK TRIGGER (-)	Tied In With Doors	
FACTORY ALARM ARM	Arms with factory remote only	
FACTORY ALARM DISARM	Disarms with factory remote only	
TACHOMETER	BLUE or RED/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	BLUE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	GREEN/YELLOW	At Window Switch In Driver's Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	At Window Switch In Driver's Door
RIGHT REAR WINDOW UP	BLUE/WHITE	At Window Switch In Driver's Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	At Window Switch In Driver's Door

WIRING INFORMATION 2004 Subaru Forester

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	RED/WHITE	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
POWER DOOR UNLOCK (-)	YELLOW/RED	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	YELLOW	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
TRUNK TRIGGER (-)	Tied In With Doors	
FACTORY ALARM ARM	Arms with factory remote only	
FACTORY ALARM DISARM	Disarms with factory remote only	
TACHOMETER	BLUE or RED/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	BLUE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	GREEN/YELLOW	At Window Switch In Driver's Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	At Window Switch In Driver's Door
RIGHT REAR WINDOW UP	BLUE/WHITE	At Window Switch In Driver's Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	At Window Switch In Driver's Door

WIRING INFORMATION 2005 Subaru Forester

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	RED/WHITE	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
POWER DOOR UNLOCK (-)	YELLOW/RED	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	YELLOW	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
TRUNK TRIGGER (-)	Tied In With Doors	
FACTORY ALARM ARM	Arms with factory remote only	
FACTORY ALARM DISARM	Disarms with factory remote only	
TACHOMETER	BLUE or RED/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	BLUE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	GREEN/YELLOW	At Window Switch In Driver's Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	At Window Switch In Driver's Door
RIGHT REAR WINDOW UP	BLUE/WHITE	At Window Switch In Driver's Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	At Window Switch In Driver's Door

WIRING INFORMATION 2006 Subaru Forester

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	RED/WHITE	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
POWER DOOR UNLOCK (-)	YELLOW/RED	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	YELLOW	At Factory Keyless Entry Module Under Dash To The Left Of The Steering Column
TRUNK TRIGGER (-)	Tied In With Doors	
FACTORY ALARM ARM	Arms with factory remote only	
FACTORY ALARM DISARM	Disarms with factory remote only	
TACHOMETER	BLUE or RED/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	BLUE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	GREEN/YELLOW	At Window Switch In Driver's Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	At Window Switch In Driver's Door
RIGHT REAR WINDOW UP	BLUE/WHITE	At Window Switch In Driver's Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	At Window Switch In Driver's Door