

# **TRIPLE S** *Customs*

## **SUBARU OUTBACK 2000-2004 VEHICLE WIRING**

WIRING INFORMATION 2000 Subaru Outback

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	PINK/BLACK	In White Connector Behind Fuse Box
TRUNK TRIGGER (-)	YELLOW/BLUE	In White Connector Behind Fuse Box
TRUNK RELEASE (5-wire)	LT.GREEN/YELLOW	At Motor In Tail Gate
FACTORY ALARM ARM (-)	Factory remote only	
FACTORY ALARM DISARM (-)	Factory remote only	
TACHOMETER	YELLOW/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2001 Subaru Outback

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	PINK/BLACK	In White Connector Behind Fuse Box
TRUNK TRIGGER (-)	YELLOW/BLUE	In White Connector Behind Fuse Box
TRUNK RELEASE (5-wire)	LT.GREEN/YELLOW	At Motor In Tail Gate
FACTORY ALARM ARM (-)	Factory remote only	
FACTORY ALARM DISARM (-)	Factory remote only	
TACHOMETER	YELLOW/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2002 Subaru Outback

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	PINK/BLACK	In White Connector Behind Fuse Box
TRUNK TRIGGER (-)	YELLOW/BLUE	In White Connector Behind Fuse Box
TRUNK RELEASE (5-wire)	LT.GREEN/YELLOW	At Motor In Tail Gate
FACTORY ALARM ARM (-)	Factory remote only	
FACTORY ALARM DISARM (-)	Factory remote only	
TACHOMETER	YELLOW/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2003 Subaru Outback

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	PINK/BLACK	In White Connector Behind Fuse Box
TRUNK TRIGGER (-)	YELLOW/BLUE	In White Connector Behind Fuse Box
TRUNK RELEASE (5-wire)	LT.GREEN/YELLOW	At Motor In Tail Gate
FACTORY ALARM ARM (-)	Factory remote only	
FACTORY ALARM DISARM (-)	Factory remote only	
TACHOMETER	YELLOW/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2004 Subaru Outback

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	PINK/BLACK	In White Connector Behind Fuse Box
TRUNK TRIGGER (-)	YELLOW/BLUE	In White Connector Behind Fuse Box
TRUNK RELEASE (5-wire)	LT.GREEN/YELLOW	At Motor In Tail Gate
FACTORY ALARM ARM (-)	Factory remote only	
FACTORY ALARM DISARM (-)	Factory remote only	
TACHOMETER	YELLOW/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door