

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE/BLUE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
Notes: When installing a remote start, the second ignition wire (BLACK/RED) must be isolated from the key switch		
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	At Headlight Switch
POWER DOOR LOCK (-)	BROWN/YELLOW	Harness In Passenger's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/BLACK	Harness In Passenger's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	At Top Of Fuse Box
TRUNK TRIGGER (-)	RED/BLUE	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	BLACK	At Diagnostic Plug Under Driver's Side Of Dash
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	WHITE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio	
12V SWITCHED	GRAY	Radio	
RADIO GROUND	BROWN	Radio	
ILLUMINATION (+)	GREEN	Radio	
LEFT FRONT SPEAKER (+)	PINK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8202, SCOSCHE TA2045B		METRA 70-1761, SCOSCHE TA02B/BCB	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE/BLUE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
Notes: When installing a remote start, the second ignition wire (BLACK/RED) must be isolated from the key switch		
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	At Headlight Switch
POWER DOOR LOCK (-)	BROWN/YELLOW	Harness In Passenger's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/BLACK	Harness In Passenger's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	At Top Of Fuse Box
TRUNK TRIGGER (-)	RED/BLUE	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	BLACK	At Diagnostic Plug Under Driver's Side Of Dash
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	WHITE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio	
12V SWITCHED	GRAY	Radio	
RADIO GROUND	BROWN	Radio	
ILLUMINATION (+)	GREEN	Radio	
LEFT FRONT SPEAKER (+)	PINK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8202, SCOSCHE TA2045B		METRA 70-1761, SCOSCHE TA02B/BCB	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE/BLUE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
Notes: When installing a remote start, the second ignition wire (BLACK/RED) must be isolated from the key switch		
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	At Headlight Switch
POWER DOOR LOCK (-)	BROWN/YELLOW	Harness In Passenger's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/BLACK	Harness In Passenger's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	At Top Of Fuse Box
TRUNK TRIGGER (-)	RED/BLUE	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	BLACK	At Diagnostic Plug Under Driver's Side Of Dash
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	WHITE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio	
12V SWITCHED	GRAY	Radio	
RADIO GROUND	BROWN	Radio	
ILLUMINATION (+)	GREEN	Radio	
LEFT FRONT SPEAKER (+)	PINK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8202, SCOSCHE TA2045B		METRA 70-1761, SCOSCHE TA02B/BCB	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE/BLUE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
Notes: When installing a remote start, the second ignition wire (BLACK/RED) must be isolated from the key switch		
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	At Headlight Switch
POWER DOOR LOCK (-)	BROWN/YELLOW	Harness In Passenger's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/BLACK	Harness In Passenger's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	At Top Of Fuse Box
TRUNK TRIGGER (-)	RED/BLUE	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	BLACK	At Diagnostic Plug Under Driver's Side Of Dash
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	WHITE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio	
12V SWITCHED	GRAY	Radio	
RADIO GROUND	BROWN	Radio	
ILLUMINATION (+)	GREEN	Radio	
LEFT FRONT SPEAKER (+)	PINK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8202, SCOSCHE TA2045B		METRA 70-1761, SCOSCHE TA02B/BCB	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE/BLUE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
Notes: When installing a remote start, the second ignition wire (BLACK/RED) must be isolated from the key switch		
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	At Headlight Switch
POWER DOOR LOCK (-)	BROWN/YELLOW	Harness In Passenger's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/BLACK	Harness In Passenger's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	At Top Of Fuse Box
TRUNK TRIGGER (-)	RED/BLUE	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	BLACK	At Diagnostic Plug Under Driver's Side Of Dash
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	WHITE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio	
12V SWITCHED	GRAY	Radio	
RADIO GROUND	BROWN	Radio	
ILLUMINATION (+)	GREEN	Radio	
LEFT FRONT SPEAKER (+)	PINK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8202, SCOSCHE TA2045B		METRA 70-1761, SCOSCHE TA02B/BCB	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE/BLUE	Ignition Harness
12V IGNITION WIRE	BLACK/RED	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
KEY SENSE WIRE (-)	YELLOW	Ignition Harness

Notes: A pulse to this wire from the remote start will disarm the factory security without unlocking the doors.

POWER DOOR LOCK (-)	BLACK/RED or BROWN/YELLOW	In 14-Pin Plug In Driver's Kick Panel
---------------------	---------------------------	---------------------------------------

Notes: Test door lock wires while turning key in driver's door. Unlock requires a double pulse

POWER DOOR UNLOCK (-)	BLUE/YELLOW or YELLOW/BLACK	In 14-Pin Plug In Driver's Kick Panel
-----------------------	-----------------------------	---------------------------------------

Notes: Test door lock wires while turning key in driver's door. Unlock requires a double pulse

PARKING LIGHTS (+)	GREEN	In 9-Pin Plug At Top Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	In 9-Pin Plug At Top Of Fuse Box
TRUNK TRIGGER (-)	RED/BLUE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	BLACK	At Data Link Connector Under Fuse Box
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	WHITE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio	
12V SWITCHED	GRAY	Radio	
RADIO GROUND	BROWN	Radio	
ILLUMINATION (+)	GREEN	Radio	
LEFT FRONT SPEAKER (+)	PINK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8202, SCOSCHE TA2045B		METRA 70-1761, SCOSCHE TA02B/BCB	Not required
Please verify all part numbers before ordering.			