

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	Battery	Must Go To Battery For 12V Constant
STARTER WIRE	YELLOW/WHITE	Ignition Harness
12V IGNITION WIRE	BLUE/RED	Ignition Harness
12V ACCESSORY WIRE	PURPLE	Ignition Harness
SECOND 12V ACCESSORY WIRE	BLUE	Ignition Harness
KEY SENSE WIRE (+)	YELLOW	Ignition Harness
Notes: This wire must be energized as an ignition wire when installing a remote start system.		
POWER DOOR LOCK (-)	PURPLE/WHITE	At Module Inside Driver's Door
Notes: Test door lock wires while turning the key in the driver's door.		
POWER DOOR UNLOCK (-)	BLUE/WHITE	At Module Inside Driver's Door
Notes: Unlock requires a double pulse.		
PARKING LIGHTS (+)	WHITE (LEFT) GRAY (RIGHT)	Under Driver Side Dash At Fuse Box
DOOR TRIGGER (-)	WHITE	At Courtesy Light Under Dash
REAR HATCH TRIGGER (-)	BLUE/BLACK or PINK	In Harness In Passenger Kick Panel
REAR HATCH RELEASE (5-wire)	GRAY/WHITE	At Rear Hatch Release Relay At Fuse Box In Left Side Of Rear Hatch
HOOD TRIGGER (-)	YELLOW	At Factory Pin Switch
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
TACHOMETER WIRE	NOT GREEN/WHITE, RED/WHITE or BLACK	Any Ignition Coil
BRAKE WIRE (+)	YELLOW	At Brake Switch
HORN TRIGGER (-)	YELLOW/GRAY	At Module Attached To Fuse Box Under Driver Dash
LEFT FRONT WINDOW UP	RED/BLACK	At Switch In Left Front Door
LEFT FRONT WINDOW DOWN	PURPLE	At Switch In Left Front Door
RIGHT FRONT WINDOW UP	RED/BLACK	At Switch In Right Front Door
RIGHT FRONT WINDOW DOWN	PURPLE	At Switch In Right Front Door
LEFT REAR WINDOW UP	RED/BLACK	At Switch In Left Rear Door
LEFT REAR WINDOW DOWN	PURPLE	At Switch In Left Rear Door
RIGHT REAR WINDOW UP	RED/BLACK	At Switch In Right Rear Door
RIGHT REAR WINDOW DOWN	PURPLE	At Switch In Right Rear Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	RED	Radio	
RADIO GROUND	BROWN	Radio	
RADIO SWITCHED	PURPLE	Radio	
POWER ANTENNA	BLUE/WHITE	Radio	
LEFT FRONT SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9", 5.25"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-9225, SCOSCHE VO4150B	Not available		METRA 40-VL10, SCOSCHE VOAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	Battery	Must Go To Battery For 12V Constant
STARTER WIRE	YELLOW/WHITE	Ignition Harness
12V IGNITION WIRE	BLUE/RED	Ignition Harness
12V ACCESSORY WIRE	PURPLE	Ignition Harness
SECOND 12V ACCESSORY WIRE	BLUE	Ignition Harness
KEY SENSE WIRE (+)	YELLOW	Ignition Harness
Notes: This wire must be energized as an ignition wire when installing a remote start system.		
POWER DOOR LOCK (-)	PURPLE/WHITE	At Module Inside Driver's Door
Notes: Test door lock wires while turning the key in the driver's door.		
POWER DOOR UNLOCK (-)	BLUE/WHITE	At Module Inside Driver's Door
Notes: Unlock requires a double pulse.		
PARKING LIGHTS (+)	WHITE (LEFT) GRAY (RIGHT)	Under Driver Side Dash At Fuse Box
DOOR TRIGGER (-)	WHITE	At Courtesy Light Under Dash
REAR HATCH TRIGGER (-)	BLUE/BLACK or PINK	In Harness In Passenger Kick Panel
REAR HATCH RELEASE (5-wire)	GRAY/WHITE	At Rear Hatch Release Relay At Fuse Box In Left Side Of Rear Hatch
HOOD TRIGGER (-)	YELLOW	At Factory Pin Switch
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
TACHOMETER WIRE	NOT GREEN/WHITE, RED/WHITE or BLACK	Any Ignition Coil
BRAKE WIRE (+)	YELLOW	At Brake Switch
HORN TRIGGER (-)	YELLOW/GRAY	At Module Attached To Fuse Box Under Driver Dash
LEFT FRONT WINDOW UP	RED/BLACK	At Switch In Left Front Door
LEFT FRONT WINDOW DOWN	PURPLE	At Switch In Left Front Door
RIGHT FRONT WINDOW UP	RED/BLACK	At Switch In Right Front Door
RIGHT FRONT WINDOW DOWN	PURPLE	At Switch In Right Front Door
LEFT REAR WINDOW UP	RED/BLACK	At Switch In Left Rear Door
LEFT REAR WINDOW DOWN	PURPLE	At Switch In Left Rear Door
RIGHT REAR WINDOW UP	RED/BLACK	At Switch In Right Rear Door
RIGHT REAR WINDOW DOWN	PURPLE	At Switch In Right Rear Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	RED	Radio	
RADIO GROUND	BROWN	Radio	
RADIO SWITCHED	PURPLE	Radio	
POWER ANTENNA	BLUE/WHITE	Radio	
LEFT FRONT SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9", 5.25"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-9225, SCOSCHE VO4150B	Not available		SCOSCHE VOAB
Please verify all part numbers before ordering.			