

TRIPLE S *Customs*

HYUNDAI SANTE FE 2001-2005 VEHICLE WIRING

WIRING INFORMATION 2001 Hyundai Santa Fe

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED and BLUE	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
SECOND IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	LT.GREEB/BLACK	Ignition harness
POWER DOOR LOCK (-)	YELLOW	White Connector In Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/BLACK	White Connector In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN/ORANGE	Connector At Fuse Box
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	YELLOW	Connector At Fuse Box
TRUNK TRIGGER (-)	BLACK/ORANGE	Connector At Fuse Box
FACTORY ALARM ARM	Arms with factory remote only	
FACTORY ALARM DISARM	Disarms with factory remote only	
FACTORY DISARM NO UNLOCK	Disarms with start	
TACHOMETER WIRE	WHITE/BLACK or BLUE	At ECM Under The Center Console To The Right Of The Gas Pedal
BRAKE WIRE (+)	GREEN/BLACK	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BROWN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BROWN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GRAY	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	PINK	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2002 Hyundai Santa Fe

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED and ORANGE	Ignition harness
12V IGNITION WIRE	BLUE	Ignition harness
SECOND IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	GREEN	Ignition harness
STARTER WIRE	BLUE	Ignition harness
POWER DOOR LOCK (-)	YELLOW	White Connector In Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/BLACK	White Connector In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN/ORANGE	Connector At Fuse Box
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	YELLOW	Connector At Fuse Box
TRUNK TRIGGER (-)	BLACK/ORANGE	Connector At Fuse Box
FACTORY ALARM ARM	Arms with factory remote only	
FACTORY ALARM DISARM	Disarms with factory remote only	
FACTORY DISARM NO UNLOCK	Disarms with start	
TACHOMETER WIRE	WHITE/BLACK or BLUE	At ECM Under The Center Console To The Right Of The Gas Pedal
BRAKE WIRE (+)	GREEN/BLACK	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BROWN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BROWN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GRAY	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	PINK	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2003 Hyundai Santa Fe

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED and ORANGE	Ignition harness
12V IGNITION WIRE	BLUE	Ignition harness
SECOND IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	GREEN	Ignition harness
STARTER WIRE	BLUE	Ignition harness
POWER DOOR LOCK (-)	YELLOW	White Connector In Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/BLACK	White Connector In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN/ORANGE	Connector At Fuse Box
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	YELLOW	Connector At Fuse Box
TRUNK TRIGGER (-)	BLACK/ORANGE	Connector At Fuse Box
FACTORY ALARM ARM	Arms with factory remote only	
FACTORY ALARM DISARM	Disarms with factory remote only	
FACTORY DISARM NO UNLOCK	Disarms with start	
TACHOMETER WIRE	WHITE/BLACK or BLUE	At ECM Under The Center Console To The Right Of The Gas Pedal
BRAKE WIRE (+)	GREEN/BLACK	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BROWN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BROWN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GRAY	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	PINK	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2004 Hyundai Santa Fe

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED and ORANGE	Ignition harness
12V IGNITION WIRE	BLUE	Ignition harness
SECOND IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	GREEN	Ignition harness
STARTER WIRE	BLUE	Ignition harness
POWER DOOR LOCK (-)	YELLOW	White Connector In Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/BLACK	White Connector In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN/ORANGE	Connector At Fuse Box
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	YELLOW	Connector At Fuse Box
TRUNK TRIGGER (-)	BLACK/ORANGE	Connector At Fuse Box
FACTORY ALARM ARM	Arms with factory remote only	
FACTORY ALARM DISARM	Disarms with factory remote only	
FACTORY DISARM NO UNLOCK	Disarms with start	
TACHOMETER WIRE	WHITE/BLACK or BLUE	At ECM Under The Center Console To The Right Of The Gas Pedal
BRAKE WIRE (+)	GREEN/BLACK	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BROWN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BROWN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GRAY	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	PINK	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2005 Hyundai Santa Fe

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED and ORANGE	Ignition harness
12V IGNITION WIRE	BLUE	Ignition harness
SECOND IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	GREEN	Ignition harness
STARTER WIRE	BLUE	Ignition harness
POWER DOOR LOCK (-)	YELLOW	White Connector In Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/BLACK	White Connector In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN/ORANGE	Connector At Fuse Box
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	YELLOW	Connector At Fuse Box
TRUNK TRIGGER (-)	BLACK/ORANGE	Connector At Fuse Box
FACTORY ALARM ARM	Arms with factory remote only	
FACTORY ALARM DISARM	Disarms with factory remote only	
FACTORY DISARM NO UNLOCK	Disarms with start	
TACHOMETER WIRE	WHITE/BLACK or BLUE	At ECM Under The Center Console To The Right Of The Gas Pedal
BRAKE WIRE (+)	GREEN/BLACK	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BROWN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BROWN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GRAY	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	PINK	Harness In Driver's Kick From Driver Door