

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BROWN	Ignition Harness
STARTER WIRE	WHITE/RED	Ignition Harness
IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	WHITE	Ignition Harness
POWER DOOR LOCK (-)	PINK/RED	At Door Lock Switch Or Fuse Box Behind Glove Box
POWER DOOR UNLOCK (-)	YELLOW/PINK	At Door Lock Switch Or Fuse Box Behind Glove Box
PARKING LIGHTS (+)	RED/WHITE	Fuse Box Behind Glove Box
LEFT FRONT DOOR TRIGGER (-)	BLACK/BROWN	Fuse Box Behind Glove Box
RIGHT FRONT DOOR TRIGGER (-)	BLACK/BLUE	Fuse Box Behind Glove Box
LEFT REAR DOOR TRIGGER (-)	PURPLE/LT.GREEN	Fuse Box Behind Glove Box
RIGHT REAR DOOR TRIGGER (-)	PURPLE/LT.GREEN	Fuse Box Behind Glove Box
DOME SUPERVISION (+)	PURPLE	Fuse Box Behind Glove Box
HOOD TRIGGER (-)	PURPLE/ORANGE	Fuse Box Behind Glove Box
REAR HATCH TRIGGER (-)	BLACK/RED	Fuse Box Behind Glove Box
REAR HATCH RELEASE (-)	BLACK/GRAY or PINK/GRAY	Fuse Box Behind Glove Box
Notes: Wire changes color. Use opener on rear door to test this wire.		
TACHOMETER	NOT BROWN/RED	Any Fuel Injector
FACTORY ALARM ARM (-)	BLACK/YELLOW	Fuse Box Behind Glove Box
FACTORY ALARM DISARM (-)	BLACK/WHITE	Fuse Box Behind Glove Box
Notes: Test arm and disarm wires while turning key in driver's door. Arm and disarm wires will also operate the door locks		
BRAKE WIRE (+)	GREEN/PURPLE	Plug At Brake Pedal Switch
HORN TRIGGER (-)	PURPLE/ORANGE	Fuse Box Behind Glove Box
LEFT FRONT WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT FRONT WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT FRONT WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT FRONT WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT REAR WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT REAR WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT REAR WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT REAR WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	VIOLET OR VIOLET/WHITE	Radio Harness	
RADIO SWITCHED	DATA BUS	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BROWN	Radio Harness	
POWER ANTENNA (+)	BLUE	Radio Harness	
AMP TURN ON (+)	BLUE	Radio Harness	
LEFT FRONT SPEAKER(+)	GREEN	Speaker or Amplifier Under Driver Seat	
LEFT FRONT SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
None available	None available		None available
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BROWN	Ignition Harness
STARTER WIRE	WHITE/RED	Ignition Harness
IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	WHITE	Ignition Harness
POWER DOOR LOCK (-)	PINK/RED	At Door Lock Switch Or Fuse Box Behind Glove Box
POWER DOOR UNLOCK (-)	YELLOW/PINK	At Door Lock Switch Or Fuse Box Behind Glove Box
PARKING LIGHTS (+)	RED/WHITE	Fuse Box Behind Glove Box
LEFT FRONT DOOR TRIGGER (-)	BLACK/BROWN	Fuse Box Behind Glove Box
RIGHT FRONT DOOR TRIGGER (-)	BLACK/BLUE	Fuse Box Behind Glove Box
LEFT REAR DOOR TRIGGER (-)	PURPLE/LT.GREEN	Fuse Box Behind Glove Box
RIGHT REAR DOOR TRIGGER (-)	PURPLE/LT.GREEN	Fuse Box Behind Glove Box
DOMESUPERVISION (+)	PURPLE	Fuse Box Behind Glove Box
HOOD TRIGGER (-)	PURPLE/ORANGE	Fuse Box Behind Glove Box
REAR HATCH TRIGGER (-)	BLACK/RED	Fuse Box Behind Glove Box
REAR HATCH RELEASE (-)	BLACK/GRAY or PINK/GRAY	Fuse Box Behind Glove Box
Notes: Wire changes color. Use opener on rear door to test this wire.		
TACHOMETER	NOT BROWN/RED	Any Fuel Injector
FACTORY ALARM ARM (-)	BLACK/YELLOW	Fuse Box Behind Glove Box
FACTORY ALARM DISARM (-)	BLACK/WHITE	Fuse Box Behind Glove Box
Notes: Test arm and disarm wires while turning key in driver's door. Arm and disarm wires will also operate the door locks		
BRAKE WIRE (+)	GREEN/PURPLE	Plug At Brake Pedal Switch
HORN TRIGGER (-)	PURPLE/ORANGE	Fuse Box Behind Glove Box
LEFT FRONT WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT FRONT WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT FRONT WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT FRONT WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT REAR WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT REAR WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT REAR WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT REAR WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	VIOLET OR VIOLET/WHITE	Radio Harness	
RADIO SWITCHED	DATA BUS	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BROWN	Radio Harness	
POWER ANTENNA (+)	BLUE	Radio Harness	
AMP TURN ON (+)	BLUE	Radio Harness	
LEFT FRONT SPEAKER(+)	GREEN	Speaker or Amplifier Under Driver Seat	
LEFT FRONT SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
None available	None available		None available
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BROWN	Ignition Harness
STARTER WIRE	WHITE/RED	Ignition Harness
IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	WHITE	Ignition Harness
POWER DOOR LOCK (-)	PINK/RED	At Door Lock Switch Or Fuse Box Behind Glove Box
POWER DOOR UNLOCK (-)	YELLOW/PINK	At Door Lock Switch Or Fuse Box Behind Glove Box
PARKING LIGHTS (+)	RED/WHITE	Fuse Box Behind Glove Box
LEFT FRONT DOOR TRIGGER (-)	BLACK/BROWN	Fuse Box Behind Glove Box
RIGHT FRONT DOOR TRIGGER (-)	BLACK/BLUE	Fuse Box Behind Glove Box
LEFT REAR DOOR TRIGGER (-)	PURPLE/LT.GREEN	Fuse Box Behind Glove Box
RIGHT REAR DOOR TRIGGER (-)	PURPLE/LT.GREEN	Fuse Box Behind Glove Box
DOMESUPERVISION (+)	PURPLE	Fuse Box Behind Glove Box
HOOD TRIGGER (-)	PURPLE/ORANGE	Fuse Box Behind Glove Box
REAR HATCH TRIGGER (-)	BLACK/RED	Fuse Box Behind Glove Box
REAR HATCH RELEASE (-)	BLACK/GRAY or PINK/GRAY	Fuse Box Behind Glove Box
Notes: Wire changes color. Use opener on rear door to test this wire.		
TACHOMETER	NOT BROWN/RED	Any Fuel Injector
FACTORY ALARM ARM (-)	BLACK/YELLOW	Fuse Box Behind Glove Box
FACTORY ALARM DISARM (-)	BLACK/WHITE	Fuse Box Behind Glove Box
Notes: Test arm and disarm wires while turning key in driver's door. Arm and disarm wires will also operate the door locks		
BRAKE WIRE (+)	GREEN/PURPLE	Plug At Brake Pedal Switch
HORN TRIGGER (-)	PURPLE/ORANGE	Fuse Box Behind Glove Box
LEFT FRONT WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT FRONT WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT FRONT WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT FRONT WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT REAR WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT REAR WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT REAR WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT REAR WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	VIOLET OR VIOLET/WHITE	Radio Harness	
RADIO SWITCHED	DATA BUS	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BROWN	Radio Harness	
POWER ANTENNA (+)	BLUE	Radio Harness	
AMP TURN ON (+)	BLUE	Radio Harness	
LEFT FRONT SPEAKER(+)	GREEN	Speaker or Amplifier Under Driver Seat	
LEFT FRONT SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
None available	None available		None available
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BROWN	Ignition Harness
STARTER WIRE	WHITE/RED	Ignition Harness
IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	WHITE	Ignition Harness
POWER DOOR LOCK (-)	PINK/RED	At Door Lock Switch Or Fuse Box Behind Glove Box
POWER DOOR UNLOCK (-)	YELLOW/PINK	At Door Lock Switch Or Fuse Box Behind Glove Box
PARKING LIGHTS (+)	RED/WHITE	Fuse Box Behind Glove Box
LEFT FRONT DOOR TRIGGER (-)	BLACK/BROWN	Fuse Box Behind Glove Box
RIGHT FRONT DOOR TRIGGER (-)	BLACK/BLUE	Fuse Box Behind Glove Box
LEFT REAR DOOR TRIGGER (-)	PURPLE/LT.GREEN	Fuse Box Behind Glove Box
RIGHT REAR DOOR TRIGGER (-)	PURPLE/LT.GREEN	Fuse Box Behind Glove Box
DOMESUPERVISION (+)	PURPLE	Fuse Box Behind Glove Box
HOOD TRIGGER (-)	PURPLE/ORANGE	Fuse Box Behind Glove Box
REAR HATCH TRIGGER (-)	BLACK/RED	Fuse Box Behind Glove Box
REAR HATCH RELEASE (-)	BLACK/GRAY or PINK/GRAY	Fuse Box Behind Glove Box
Notes: Wire changes color. Use opener on rear door to test this wire.		
TACHOMETER	NOT BROWN/RED	Any Fuel Injector
FACTORY ALARM ARM (-)	BLACK/YELLOW	Fuse Box Behind Glove Box
FACTORY ALARM DISARM (-)	BLACK/WHITE	Fuse Box Behind Glove Box
Notes: Test arm and disarm wires while turning key in driver's door. Arm and disarm wires will also operate the door locks		
BRAKE WIRE (+)	GREEN/PURPLE	Plug At Brake Pedal Switch
HORN TRIGGER (-)	PURPLE/ORANGE	Fuse Box Behind Glove Box
LEFT FRONT WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT FRONT WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT FRONT WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT FRONT WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT REAR WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT REAR WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT REAR WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT REAR WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	VIOLET OR VIOLET/WHITE	Radio Harness	
RADIO SWITCHED	DATA BUS	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BROWN	Radio Harness	
POWER ANTENNA (+)	BLUE	Radio Harness	
AMP TURN ON (+)	BLUE	Radio Harness	
LEFT FRONT SPEAKER(+)	GREEN	Speaker or Amplifier Under Driver Seat	
LEFT FRONT SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
None available	None available		None available
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BROWN	Ignition Harness
STARTER WIRE	WHITE/RED	Ignition Harness
IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	WHITE	Ignition Harness
POWER DOOR LOCK (-)	PINK/RED	At Door Lock Switch Or Fuse Box Behind Glove Box
POWER DOOR UNLOCK (-)	YELLOW/PINK	At Door Lock Switch Or Fuse Box Behind Glove Box
PARKING LIGHTS (+)	RED/WHITE	Fuse Box Behind Glove Box
LEFT FRONT DOOR TRIGGER (-)	BLACK/BROWN	Fuse Box Behind Glove Box
RIGHT FRONT DOOR TRIGGER (-)	BLACK/BLUE	Fuse Box Behind Glove Box
LEFT REAR DOOR TRIGGER (-)	PURPLE/LT.GREEN	Fuse Box Behind Glove Box
RIGHT REAR DOOR TRIGGER (-)	PURPLE/LT.GREEN	Fuse Box Behind Glove Box
DOMESUPERVISION (+)	PURPLE	Fuse Box Behind Glove Box
HOOD TRIGGER (-)	PURPLE/ORANGE	Fuse Box Behind Glove Box
REAR HATCH TRIGGER (-)	BLACK/RED	Fuse Box Behind Glove Box
REAR HATCH RELEASE (-)	BLACK/GRAY or PINK/GRAY	Fuse Box Behind Glove Box
Notes: Wire changes color. Use opener on rear door to test this wire.		
TACHOMETER	NOT BROWN/RED	Any Fuel Injector
FACTORY ALARM ARM (-)	BLACK/YELLOW	Fuse Box Behind Glove Box
FACTORY ALARM DISARM (-)	BLACK/WHITE	Fuse Box Behind Glove Box
Notes: Test arm and disarm wires while turning key in driver's door. Arm and disarm wires will also operate the door locks		
BRAKE WIRE (+)	GREEN/PURPLE	Plug At Brake Pedal Switch
HORN TRIGGER (-)	PURPLE/ORANGE	Fuse Box Behind Glove Box
LEFT FRONT WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT FRONT WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT FRONT WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT FRONT WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT REAR WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
LEFT REAR WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT REAR WINDOW UP		
Notes: Unable to do. Window motor is part of the module that operates it.		
RIGHT REAR WINDOW DOWN		
Notes: Unable to do. Window motor is part of the module that operates it.		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	VIOLET OR VIOLET/WHITE	Radio Harness	
RADIO SWITCHED	DATA BUS	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BROWN	Radio Harness	
POWER ANTENNA (+)	BLUE	Radio Harness	
AMP TURN ON (+)	BLUE	Radio Harness	
LEFT FRONT SPEAKER(+)	GREEN	Speaker or Amplifier Under Driver Seat	
LEFT FRONT SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (+)	GREEN	Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (-)	GREEN/WHITE	Speaker or Amplifier Under Driver Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
None available		None available	None available
Please verify all part numbers before ordering.			