

TRIPLE S *Customs*

**PLYMOUTH LASER 1990-1994
VEHICLE WIRING**

WIRING INFORMATION: 1990 Plymouth Laser

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE or BLACK	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
12V ACCESSORY WIRE	BLUE/BLACK	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Relays On Right Side Of Steering Column
POWER DOOR UNLOCK (-)	BROWN/WHITE	At Relays On Right Side Of Steering Column
PARKING LIGHTS (+)	GREEN/WHITE	Harness Under Dash Above Hood Release Cable
DOOR TRIGGER (-)	GREEN/RED	Harness Under Dash Above Hood Release Cable
TRUNK TRIGGER		Tied In With Doors
DOMELIGHT SUPERVISION (-)		Use Door Trigger
TACHOMETER WIRE	WHITE	At Instrument Cluster Or Ignition Coil
FACTORY ALARM DISARM (-)	BROWN/WHITE or BROWN/BLACK	Harness Coming Into Vehicle From Driver's Door
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-/+)	GREEN/BLACK (-) and GREEN/WHITE (+)	At Harness At Steering Column At Fuse Box
<ul style="list-style-type: none"> The horn only works when the ignition is on. To honk horn, wire a relay to pulse positive to GREEN/WHITE and one to pulse negative to GREEN/BLACK at the steering column. The GREEN/WHITE can be found at the fuse box. 		
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1991 Plymouth Laser

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE or BLACK	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
12V ACCESSORY WIRE	BLUE/BLACK	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Relays On Right Side Of Steering Column
POWER DOOR UNLOCK (-)	BROWN/WHITE	At Relays On Right Side Of Steering Column
PARKING LIGHTS (+)	GREEN/WHITE	Harness Under Dash Above Hood Release Cable
DOOR TRIGGER (-)	GREEN/RED	Harness Under Dash Above Hood Release Cable
TRUNK TRIGGER		Tied In With Doors
DOMELIGHT SUPERVISION (-)		Use Door Trigger
TACHOMETER WIRE	WHITE	At Instrument Cluster Or Ignition Coil
FACTORY ALARM DISARM (-)	BROWN/WHITE or BROWN/BLACK	Harness Coming Into Vehicle From Driver's Door
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-/+)	GREEN/BLACK (-) and GREEN/WHITE (+)	At Harness At Steering Column At Fuse Box
<ul style="list-style-type: none"> The horn only works when the ignition is on. To honk horn, wire a relay to pulse positive to GREEN/WHITE and one to pulse negative to GREEN/BLACK at the steering column. The GREEN/WHITE can be found at the fuse box. 		
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1992 Plymouth Laser

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE or BLACK	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
12V ACCESSORY WIRE	BLUE/BLACK	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Relays On Right Side Of Steering Column
POWER DOOR UNLOCK (-)	BROWN/WHITE	At Relays On Right Side Of Steering Column
PARKING LIGHTS (+)	GREEN/WHITE	Harness Under Dash Above Hood Release Cable
DOOR TRIGGER (-)	GREEN/RED	Harness Under Dash Above Hood Release Cable
TRUNK TRIGGER		Tied In With Doors
DOMELIGHT SUPERVISION (-)		Use Door Trigger
TACHOMETER WIRE	WHITE	At Instrument Cluster Or Ignition Coil
FACTORY ALARM DISARM (-)	BROWN/WHITE or BROWN/BLACK	Harness Coming Into Vehicle From Driver's Door
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-/+)	GREEN/BLACK (-) and GREEN/WHITE (+)	At Harness At Steering Column At Fuse Box
<ul style="list-style-type: none"> The horn only works when the ignition is on. To honk horn, wire a relay to pulse positive to GREEN/WHITE and one to pulse negative to GREEN/BLACK at the steering column. The GREEN/WHITE can be found at the fuse box. 		
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1993 Plymouth Laser

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE or BLACK	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
12V ACCESSORY WIRE	BLUE/BLACK	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Relays On Right Side Of Steering Column
POWER DOOR UNLOCK (-)	BROWN/WHITE	At Relays On Right Side Of Steering Column
PARKING LIGHTS (+)	GREEN/WHITE	Harness Under Dash Above Hood Release Cable
DOOR TRIGGER (-)	GREEN/RED	Harness Under Dash Above Hood Release Cable
TRUNK TRIGGER		Tied In With Doors
DOMELIGHT SUPERVISION (-)		Use Door Trigger
TACHOMETER WIRE	WHITE	At Instrument Cluster Or Ignition Coil
FACTORY ALARM DISARM (-)	BROWN/WHITE or BROWN/BLACK	Harness Coming Into Vehicle From Driver's Door
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-/+)	GREEN/BLACK (-) and GREEN/WHITE (+)	At Harness At Steering Column At Fuse Box
<ul style="list-style-type: none"> The horn only works when the ignition is on. To honk horn, wire a relay to pulse positive to GREEN/WHITE and one to pulse negative to GREEN/BLACK at the steering column. The GREEN/WHITE can be found at the fuse box. 		
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1994 Plymouth Laser

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE or BLACK	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
12V ACCESSORY WIRE	BLUE/BLACK	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Relays On Right Side Of Steering Column
POWER DOOR UNLOCK (-)	BROWN/WHITE	At Relays On Right Side Of Steering Column
PARKING LIGHTS (+)	GREEN/WHITE	Harness Under Dash Above Hood Release Cable
DOOR TRIGGER (-)	GREEN/RED	Harness Under Dash Above Hood Release Cable
TRUNK TRIGGER		Tied In With Doors
DOMELIGHT SUPERVISION (-)		Use Door Trigger
TACHOMETER WIRE	WHITE	At Instrument Cluster Or Ignition Coil
FACTORY ALARM DISARM (-)	BROWN/WHITE or BROWN/BLACK	Harness Coming Into Vehicle From Driver's Door
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-/+)	GREEN/BLACK (-) and GREEN/WHITE (+)	At Harness At Steering Column At Fuse Box
<ul style="list-style-type: none"> The horn only works when the ignition is on. To honk horn, wire a relay to pulse positive to GREEN/WHITE and one to pulse negative to GREEN/BLACK at the steering column. The GREEN/WHITE can be found at the fuse box. 		
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door