

TRIPLE S *Customs*

TOYOTA SOLARA 1999-2004 VEHICLE WIRING

WIRING INFORMATION: 1999 Toyota Solara

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE - WHITE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	DK. BLUE/WHITE	Harness In The Passenger Kick Panel, Also Located In Harness At Bottom Left Of Fuse Bo
POWER DOOR UNLOCK (-)	DK. BLUE	Harness In The Passenger Kick Panel, Also Located In Harness At Bottom Left Of Fuse Bo
Test door lock wires using key in the passenger door.		
PARKING LIGHTS (+)	GREEN	Harness At Bottom Right Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness On Right Side Of Fuse Box
DOMESUPERVISION (-)	RED/WHITE	Harness At Top Right Of Fuse Box
TRUNK TRIGGER (-)	RED/YELLOW	At Light In Trunk, Also Sometimes Found In Driver's Kick panel
HOOD TRIGGER (-)	BLACK	At Hood Pin Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN/WHITE	Bundle Of Wires In Drivers Running Board
TACHOMETER WIRE	BLACK/ORANGE	At Engine Control Module Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Harness At Fuse Box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
This vehicle may be equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2000 Toyota Solara

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE - WHITE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	DK. BLUE/WHITE	Harness In The Passenger Kick Panel, Also Located In Harness At Bottom Left Of Fuse Bo
POWER DOOR UNLOCK (-)	DK. BLUE	Harness In The Passenger Kick Panel, Also Located In Harness At Bottom Left Of Fuse Bo
Test door lock wires using key in the passenger door.		
PARKING LIGHTS (+)	GREEN	Harness At Bottom Right Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness On Right Side Of Fuse Box
DOMESUPERVISION (-)	RED/WHITE	Harness At Top Right Of Fuse Box
TRUNK TRIGGER (-)	RED/YELLOW	At Light In Trunk, Also Sometimes Found In Driver's Kick panel
HOOD TRIGGER (-)	BLACK	At Hood Pin Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN/WHITE	Bundle Of Wires In Drivers Running Board
TACHOMETER WIRE	BLACK/ORANGE	At Engine Control Module Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Harness At Fuse Box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
This vehicle may be equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2001 Toyota Solara

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE - WHITE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	DK. BLUE/WHITE	Harness In The Passenger Kick Panel, Also Located In Harness At Bottom Left Of Fuse Bo
POWER DOOR UNLOCK (-)	DK. BLUE	Harness In The Passenger Kick Panel, Also Located In Harness At Bottom Left Of Fuse Bo
Test door lock wires using key in the passenger door.		
PARKING LIGHTS (+)	GREEN	Harness At Bottom Right Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness On Right Side Of Fuse Box
DOME SUPERVISION (-)	RED/WHITE	Harness At Top Right Of Fuse Box
TRUNK TRIGGER (-)	RED/YELLOW	At Light In Trunk, Also Sometimes Found In Driver's Kick panel
HOOD TRIGGER (-)	BLACK	At Hood Pin Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN/WHITE	Bundle Of Wires In Drivers Running Board
TACHOMETER WIRE	BLACK/ORANGE	At Engine Control Module Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Harness At Fuse Box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
This vehicle may be equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2002 Toyota Solara

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE - WHITE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	DK. BLUE/WHITE	Harness In The Passenger Kick Panel, Also Located In Harness At Bottom Left Of Fuse Bo
POWER DOOR UNLOCK (-)	DK. BLUE	Harness In The Passenger Kick Panel, Also Located In Harness At Bottom Left Of Fuse Bo
Test door lock wires using key in the passenger door.		
PARKING LIGHTS (+)	GREEN	Harness At Bottom Right Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness On Right Side Of Fuse Box
DOME SUPERVISION (-)	RED/WHITE	Harness At Top Right Of Fuse Box
TRUNK TRIGGER (-)	RED/YELLOW	At Light In Trunk, Also Sometimes Found In Driver's Kick panel
HOOD TRIGGER (-)	BLACK	At Hood Pin Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN/WHITE	Bundle Of Wires In Drivers Running Board
TACHOMETER WIRE	BLACK/ORANGE	At Engine Control Module Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Harness At Fuse Box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
This vehicle may be equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2003 Toyota Solara

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE - WHITE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	DK. BLUE/WHITE	Harness In The Passenger Kick Panel, Also Located In Harness At Bottom Left Of Fuse Bo
POWER DOOR UNLOCK (-)	DK. BLUE	Harness In The Passenger Kick Panel, Also Located In Harness At Bottom Left Of Fuse Bo
Test door lock wires using key in the passenger door.		
PARKING LIGHTS (+)	GREEN	Harness At Bottom Right Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness On Right Side Of Fuse Box
DOMESUPERVISION (-)	RED/WHITE	Harness At Top Right Of Fuse Box
TRUNK TRIGGER (-)	RED/YELLOW	At Light In Trunk, Also Sometimes Found In Driver's Kick panel
HOOD TRIGGER (-)	BLACK	At Hood Pin Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN/WHITE	Bundle Of Wires In Drivers Running Board
TACHOMETER WIRE	BLACK/ORANGE	At Engine Control Module Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Harness At Fuse Box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
This vehicle may be equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2004 Toyota Solara

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	RED/BLACK	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
KEY SENSE WIRE (-)	BLUE	Ignition Harness
POWER DOOR LOCK (-)	LT.GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
Unlock requires a double pulse.		
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	RED	Steering Column
LEFT FRONT DOOR TRIGGER (-)	RED/GREEN	Harness In Driver's Kick Panel
RIGHT FRONT DOOR TRIGGER (-)	RED/GREEN	Harness In Passenger Kick Panel
DOMESUPERVISION (-)	GREEN/RED	Harness On Right Of Fuse Box
TRUNK TRIGGER (-)	GREEN/RED	Harness In Driver's Kick Panel
HOOD TRIGGER (-)	BLACK	At Body ECU Behind Fuse Box
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK	USE KEY SENSE WIRE	
TACHOMETER WIRE	BLACK/ORANGE	At Engine Control Module Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Harness At Fuse Box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN/YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLUE	Harness In Driver's Kick From Driver Door
This vehicle may be equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		