

Vehicle Wiring Information
for the
1993 Audi 100 S

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	bottom of fusebox
STARTER	red/black	+	bottom of fusebox
IGNITION	black	+	bottom of fusebox
ACCESSORY	black/yellow	+	bottom of fusebox
POWER LOCK	green/blue *2	E	door harness
POWER UNLOCK	same wire		
PARKING LIGHTS +	gray/red, gray/black		bottom of fusebox
HEADLIGHTS	yellow (low beam)	+	bottom of fusebox
DOOR TRIGGER	brown/blue	-	any pin
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HTCH RELEASE			
FCTRY ALARM ARM	brn/blu or brn/gry	-	door harness
FCTRY ALRM DISARM	brown/green	-	door harness
TACHOMETER	yellow/blue *1		in loom at coil pack
BRAKE WIRE	red/black	+	brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			

Notes:

*1 Also found yellow/red or yellow/white. *2 This system wires just like the standard type 'E', with the exception that it only requires a standard length pulse.

Vehicle Wiring Information

for the

1989 Audi 100/200 (UK)

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	red/black		ignition harness
SECOND STARTER			
IGNITION	black		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	thin black/yellow		ignition harness
SECOND ACCESSORY	black/yellow		ignition harness
POWER LOCK	grn/red or grn/blu	E	behind o/s/f kick panel
POWER UNLOCK	same wire		
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	blk/grn & blk/wht		brn conn, steering column
PARKING LIGHTS -			
HEADLIGHTS	grn/red or grn/blk		
DOOR TRIGGER	brown/blue	-	overhead light
DOME SUPERVISION			
TRUNK/HATCH PIN	brown/black		at the bootlight
HOOD PIN			
TRNK/HTCH RELEASE	red/green		drivers kick panel
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER	green		ignition coil
SPEED SENSE			
BRAKE WIRE	red/black		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN	*1		
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

*1 Total closure may be applicable by using an extended negative pulse on a brown/grey wire.

Vehicle Wiring Information
for the
1990 Audi 100/200 (UK)

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	red/black		ignition harness
SECOND STARTER			
IGNITION	black		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	thin black/yellow		ignition harness
SECOND ACCESSORY	black/yellow		ignition harness
POWER LOCK	grn/red or grn/blu	E	behind o/s/f kick panel
POWER UNLOCK	same wire		
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	blk/grn & blk/wht		brn conn, steering column
PARKING LIGHTS -			
HEADLIGHTS	grn/red or grn/blk		
DOOR TRIGGER	brown/blue	-	overhead light
DOVE SUPERVISION			
TRUNK/HATCH PIN	brown/black		at the bootlight
HOOD PIN			
TRNK/HTCH RELEASE	red/green		drivers kick panel
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER	green		ignition coil
SPEED SENSE			
BRAKE WIRE	red/black		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN	*1		
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

*1 Total closure may be applicable by using an extended negative pulse on a brown/grey wire.

Vehicle Wiring Information
for the
1991 Audi 100/200 (UK)

ITEM	WIRE COLOR	POL	WIRE LOCATION
STARTER	12V red/black		ignition harness
SECOND STARTER	black		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	thin black/yellow		ignition harness
SECOND ACCESSORY	black/yellow		ignition harness
POWER LOCK	grn/red or grn/blu	E	behind o/s/f kick panel
POWER UNLOCK	same wire		
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	blk/grn & blk/wht		brn conn, steering column
PARKING LIGHTS -			
HEADLIGHTS	grn/red or grn/blk		
DOOR TRIGGER	brown/blue	-	overhead light
DOVE SUPERVISION			
TRUNK/HATCH PIN	brown/black		at the bootlight
HOOD PIN			
TRNK/HTCH RELEASE	red/green		drivers kick panel
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER	green		ignition coil
SPEED SENSE			
BRAKE WIRE	red/black		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN	*1		
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

*1 Total closure may be applicable by using an extended negative pulse on a brown/grey wire.

Vehicle Wiring Information

for the
1992 Audi 100/200 (UK)

ITEM	WIRE COLOR	(POL)	WIRE LOCATION
12V			
STARTER	red/black		ignition harness
SECOND STARTER			
IGNITION	black		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	thin black/yellow		ignition harness
SECOND ACCESSORY	black/yellow		ignition harness
POWER LOCK	grn/red or grn/blu	E	behind o/s/f kick panel
POWER UNLOCK	same wire		
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	blk/grn & blk/wht		brn conn, steering column
PARKING LIGHTS -			
HEADLIGHTS	grn/red or grn/blk		
DOOR TRIGGER	brown/blue	-	overhead light
DOVE SUPERVISION			
TRUNK/HATCH PIN	brown/black		at the bootlight
HOOD PIN			
TRNK/HTCH RELEASE	red/green		drivers kick panel
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER	green		ignition coil
SPEED SENSE			
BRAKE WIRE	red/black		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN	*1		
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

*1 Total closure may be applicable by using an extended negative pulse on a brown/grey wire.

Vehicle Wiring Information
for the
1993 Audi 100/200 (UK)

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	red/black		ignition harness
SECOND STARTER			
IGNITION	black		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	thin black/yellow		ignition harness
SECOND ACCESSORY	black/yellow		ignition harness
POWER LOCK	grn/red or grn/blu	E	behind o/s/f kick panel
POWER UNLOCK	same wire		
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	blk/grn & blk/wht		brn conn, steering column
PARKING LIGHTS -			
HEADLIGHTS	grn/red or grn/blk		
DOOR TRIGGER	brown/blue	-	overhead light
DOVE SUPERVISION			
TRUNK/HATCH PIN	brown/black		at the bootlight
HOOD PIN			
TRNK/HTCH RELEASE	red/green		drivers kick panel
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER	green		ignition coil
SPEED SENSE			
BRAKE WIRE	red/black		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN	*1		
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

*1 Total closure may be applicable by using an extended negative pulse on a brown/grey wire.

Vehicle Wiring Information
for the
1994 Audi 100/200 (UK)

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	red/black		ignition harness
SECOND STARTER			
IGNITION	black		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	black/yellow		ignition harness
SECOND ACCESSORY			
POWER LOCK	brown/white	-	behind o/s/f kick panel
POWER UNLOCK	brown/green	-	behind o/s/f kick panel
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	blk/grn & blk/wht		
PARKING LIGHTS -			
HEADLIGHTS			
DOOR TRIGGER	brown/yellow	-	underdash light
DOVE SUPERVISION			
TRUNK/HATCH PIN	brown/black		at the bootlight
HOOD PIN			
TRNK/HATCH RELEASE	grey *1		at switch
FCTRY ALARM ARM	arms with lock		
FCTRY ALRM DISARM	disarms with unlock		
DISARM NO UNLOCK			
TACHOMETER	green/blue		module near the coil
SPEED SENSE			
BRAKE WIRE	red/black		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN	blk/red - yel/blu		
RF WINDOW UP/DN	blk/grn - white		
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

*1 Cut the wire and relay isolate the positive trigger from the switch.