

# **TRIPLE S** *Customs*

## **DODGE RAM PICKUP 1992-2005 VEHICLE WIRING**

WIRING INFORMATION: 1992 Dodge Ram

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	DK. BLUE	Ignition Harness
ACCESSORY WIRE	BLACK/ORANGE	Ignition Harness
POWER DOOR LOCK (5-wire reverse polarity)	ORANGE/PURPLE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (5-wire reverse polarity)	PINK/PURPLE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BLACK/YELLOW	At Headlight Switch
DOOR TRIGGER (-)	YELLOW	At Headlight Switch
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
TACHOMETER WIRE	GRAY GRAY/LT.BLACK (diesels)	At Distributor At Powertrain Control Module On Driver's Inner Fender
BRAKE WIRE (+)	WHITE/TAN	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	Harness At Steering Column
DIESEL WAIT-TO-START (-)	GREEN/WHITE	At Powertrain Control Module On Driver's Inner Fender
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1993 Dodge Ram

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	DK. BLUE	Ignition Harness
ACCESSORY WIRE	BLACK/ORANGE	Ignition Harness
POWER DOOR LOCK (5-wire reverse polarity)	ORANGE/PURPLE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (5-wire reverse polarity)	PINK/PURPLE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BLACK/YELLOW	At Headlight Switch
DOOR TRIGGER (-)	YELLOW	At Headlight Switch
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
TACHOMETER WIRE	GRAY GRAY/LT.BLACK (diesels)	At Distributor At Powertrain Control Module On Driver's Inner Fender
BRAKE WIRE (+)	WHITE/TAN	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	Harness At Steering Column
DIESEL WAIT-TO-START (-)	GREEN/WHITE	At Powertrain Control Module On Driver's Inner Fender
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1994 Dodge Ram

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED or PINK/BLACK	Ignition harness
STARTER WIRE	YELLOW or BLUE/YELLOW	Ignition harness
12V IGNITION WIRE	DARK BLUE	Ignition harness
12V ACCESSORY WIRE	BLACK/ORANGE	Ignition harness
POWER DOOR LOCK (5-wire reverse polarity)	ORANGE/PURPLE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (5-wire reverse polarity)	PINK/PURPLE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BLACK/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	YELLOW	Harness In Driver's Kick Panel
TACHOMETER WIRE	GRAY/BLACK, BLACK/GRAY	At Ignition Coil
BRAKE WIRE (+)	WHITE/BROWN	At Brake pedal switch
HORN TRIGGER (-)	BLACK/RED	Harness At Steering column
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1995 Dodge Ram

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED or PINK/BLACK	Ignition harness
STARTER WIRE	YELLOW or BLUE/YELLOW	Ignition harness
12V IGNITION WIRE	DARK BLUE	Ignition harness
12V ACCESSORY WIRE	BLACK/ORANGE	Ignition harness
POWER DOOR LOCK (5-wire reverse polarity)	ORANGE/PURPLE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (5-wire reverse polarity)	PINK/PURPLE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BLACK/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	YELLOW	Harness In Driver's Kick Panel
TACHOMETER WIRE	GRAY/BLACK, BLACK/GRAY	At Ignition Coil
BRAKE WIRE (+)	WHITE/BROWN	At Brake pedal switch
HORN TRIGGER (-)	BLACK/RED	Harness At Steering column
RADIO CONSTANT	PINK or PINK/WHITE	Radio
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1996 Dodge Ram


WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED or PINK/BLACK	Ignition harness
STARTER WIRE	YELLOW or BLUE/YELLOW	Ignition harness
12V IGNITION WIRE	DARK BLUE	Ignition harness
12V ACCESSORY WIRE	BLACK/ORANGE	Ignition harness
POWER DOOR LOCK (5-wire reverse polarity)	ORANGE/PURPLE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (5-wire reverse polarity)	PINK/PURPLE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BLACK/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	YELLOW	Harness In Driver's Kick Panel
TACHOMETER WIRE	GRAY/BLACK, BLACK/GRAY	At Ignition Coil
BRAKE WIRE (+)	WHITE/BROWN	At Brake pedal switch
HORN TRIGGER (-)	BLACK/RED	Harness At Steering column
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1997 Dodge Ram

WIRE	WIRE COLOR	LOCATION
12V CONSTANT	RED or PINK/BLACK	Ignition harness
STARTER	YELLOW or BLUE/YELLOW	Ignition harness
12V IGNITION	DARK BLUE	Ignition harness
12V ACCESSORY	BLACK/ORANGE	Ignition harness
SECOND 12V ACCESSORY	BLACK/WHITE	Ignition harness
POWER LOCK (models with OEM keyless: positive trigger, models without OEM keyless: 5-wire reverse polarity)	ORANGE/PURPLE	Harness In Driver's Kick Panel
POWER UNLOCK (models with OEM keyless: positive trigger, models without OEM keyless: 5-wire reverse polarity)	PINK/PURPLE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BLACK/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	YELLOW	Harness In Driver's Kick Panel
TACHOMETER	GRAY/BLACK, BLACK.GRAY GRAY/BLACK (diesels)	Ignition coil Main Harness Across Firewall In Engine Bay
DIESEL WAIT-TO-START (-)	ORANGE/BLACK	Behind Instrument Cluster
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door



WIRING INFORMATION: 1998 Dodge Ram

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED and PINK/BLACK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V IGNITION WIRE	DARK BLUE	Ignition Harness
SECOND 12V IGNITION WIRE	BLACK/ORANGE	Ignition Harness
12V ACCESSORY WIRE	BLACK/WHITE	Ignition Harness
POWER DOOR LOCK (5-wire reverse polarity)	ORANGE/PURPLE	In White Connector In Driver's Kick Panel Coming From Driver's Door
POWER DOOR UNLOCK (5-wire reverse polarity)	PINK/PURPLE	In White Connector In Driver's Kick Panel Coming From Driver's Door
PARKING LIGHTS (+)	BLACK/YELLOW	Behind Headlight Switch
DOOR TRIGGER (-)	YELLOW	Behind Headlight Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	LT.GREEN/ORANGE	Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	BLACK/GRAY GRAY/BLACK (diesels)	Ignition Coil Harness At Top Center Of Firewall
DIESEL WAIT-TO-START (-)	ORANGE/BLACK	Behind Instrument Cluster
BRAKE WIRE (+)	WHITE/TAN	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	At Steering Column
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door





WIRING INFORMATION: 1999 Dodge Ram

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED and PINK/BLACK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V IGNITION WIRE	DARK BLUE	Ignition Harness
SECOND 12V IGNITION WIRE	BLACK/ORANGE	Ignition Harness
12V ACCESSORY WIRE	BLACK/WHITE	Ignition Harness
POWER DOOR LOCK (5-wire reverse polarity)	ORANGE/PURPLE	In White Connector In Driver's Kick Panel Coming From Driver's Door
POWER DOOR UNLOCK (5-wire reverse polarity)	PINK/PURPLE	In White Connector In Driver's Kick Panel Coming From Driver's Door
PARKING LIGHTS (+)	BLACK/YELLOW	Behind Headlight Switch
DOOR TRIGGER (-)	YELLOW	Behind Headlight Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	LT.GREEN/ORANGE	Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	BLACK/GRAY GRAY/BLACK (diesels)	Ignition Coil Harness At Top Center Of Firewall
DIESEL WAIT-TO-START (-)	ORANGE/BLACK	Behind Instrument Cluster
BRAKE WIRE (+)	WHITE/TAN	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	At Steering Column
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door




WIRING INFORMATION: 2000 Dodge Ram

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED and PINK/BLACK	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
12V IGNITION WIRE	DARK BLUE	Ignition harness
SECOND 12V IGNITION WIRE	BLACK/ORANGE	Ignition harness
12V ACCESSORY WIRE	BLACK/WHITE	Ignition harness
POWER DOOR LOCK (5-wire reverse polarity)	ORANGE/PURPLE	In White Connector In Driver's Kick Panel Coming From Driver's Door
POWER DOOR UNLOCK (5-wire reverse polarity)	PINK/PURPLE	In White Connector In Driver's Kick Panel Coming From Driver's Door
PARKING LIGHTS (+)	BLACK/YELLOW	Behind Headlight Switch.
DRIVER DOOR TRIGGER (-)	TAN	In Green Connector Of Module Right Of Steering Column
PASSENGER DOOR TRIGGER (-)	BLACK/LIGHT BLUE	In Green Connector Of Module Right Of Steering Column
FACTORY ALARM ARM AND DISARM	LT.GREEN/ORANGE	Harness Coming Into Vehicle From Driver's Door
Factory alarm arms with a negative trigger through a 644 ohm resistor. Factory alarm disarms with a negative trigger through a 1500 ohm resistor. Relays must be used.		
TACHOMETER WIRE	BLACK/GRAY GRAY/BLACK (diesels)	Ignition coil Harness In Engine Compartment Running Along Firewall
DIESEL WAIT-TO-START (-)	ORANGE/BLACK	Harness In Engine Compartment Running Along Firewall
BRAKE WIRE (+)	WHITE/TAN	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	At Harness At Steering Column
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door



WIRING INFORMATION: 2001 Dodge Ram

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED and PINK/BLACK	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
12V IGNITION WIRE	DARK BLUE	Ignition harness
SECOND 12V IGNITION WIRE	BLACK/ORANGE	Ignition harness
12V ACCESSORY WIRE	BLACK/WHITE	Ignition harness
POWER DOOR LOCK (5-wire reverse polarity)	ORANGE/PURPLE	In White Connector In Driver's Kick Panel Coming From Driver's Door
POWER DOOR UNLOCK (5-wire reverse polarity)	PINK/PURPLE	In White Connector In Driver's Kick Panel Coming From Driver's Door
PARKING LIGHTS (+)	BLACK/YELLOW	Behind Headlight Switch.
DRIVER DOOR TRIGGER (-)	TAN	In Green Connector Of Module Right Of Steering Column
PASSENGER DOOR TRIGGER (-)	BLACK/LIGHT BLUE	In Green Connector Of Module Right Of Steering Column
FACTORY ALARM ARM AND DISARM	LT.GREEN/ORANGE	Harness Coming Into Vehicle From Driver's Door
Factory alarm arms with a negative trigger through a 644 ohm resistor. Factory alarm disarms with a negative trigger through a 1500 ohm resistor. Relays must be used.		
TACHOMETER WIRE	BLACK/GRAY GRAY/BLACK (diesels)	Ignition coil Harness In Engine Compartment Running Along Firewall
DIESEL WAIT-TO-START (-)	ORANGE/BLACK	Harness In Engine Compartment Running Along Firewall
BRAKE WIRE (+)	WHITE/TAN	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	At Harness At Steering Column
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door



WIRING INFORMATION: 2002 Dodge Ram

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED/WHITE and PINK/BLACK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V IGNITION WIRE	BLUE (16 gauge)	Ignition Harness
SECOND 12V IGNITION WIRE	RED or RED/WHITE	Ignition Harness
12V ACCESSORY WIRE	GREEN	Ignition Harness
SECOND ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (Negative trigger through an 820-ohm resistor)	WHITE/GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Negative trigger through a 330-ohm resistor)	Same wire as lock	
PARKING LIGHTS (Negative trigger through a 330 or 1400-ohm resistor)	PURPLE/YELLOW	Headlight Switch
DRIVER DOOR TRIGGER (-)	TAN	Harness In Driver's Kick Panel
PASSENGER DOOR TRIGGER (-)	TAN/RED	Harness In Passenger Kick Panel
LEFT REAR DOOR TRIGGER (-)	TAN/ORANGE or PURPLE/ORANGE	Harness In Driver's Kick Panel
RIGHT REAR DOOR TRIGGER (-)	TAN/YELLOW	Harness In Passenger Kick Panel
FACTORY ALARM ARM (Negative trigger through a 2000-ohm resistor)	LT.GREEN/ORANGE	Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM DISARM (Negative trigger through a 480- ohm resistor. Double pulse will unlock doors)	Same wire as arm	
TACHOMETER WIRE	Any wire NOT GREEN/ORANGE	At Fuel Injector Or Ignition coil
DIESEL WAIT-TO-START	DO NOT interface with the vehicle's wait-to-start wire. A pulse timer relay must be used to delay the remote start's activation.	
BRAKE WIRE (+)	WHITE/TAN	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	At Harness At Steering Column
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
Models with a gray ignition key are equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		
For Dodge Ram 2500 and 3500 models, refer to info on the 2001 Dodge Ram. Also, on 2002-Up diesel models, when installing a remote start, DO NOT interface with the vehicle's wait-to-start wire. A pulse timer relay must be used to delay the remote start's activation.		

WIRING INFORMATION: 2003 Dodge Ram

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED/WHITE and PINK/BLACK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V IGNITION WIRE	BLUE (16 gauge)	Ignition Harness
SECOND 12V IGNITION WIRE	RED or RED/WHITE	Ignition Harness
12V ACCESSORY WIRE	GREEN	Ignition Harness
SECOND ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (Negative trigger through an 820-ohm resistor)	WHITE/GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Negative trigger through a 330-ohm resistor)	Same wire as lock	
PARKING LIGHTS (Negative trigger through a 330 or 1400-ohm resistor)	PURPLE/YELLOW	Headlight Switch
DRIVER DOOR TRIGGER (-)	TAN	Harness In Driver's Kick Panel
PASSENGER DOOR TRIGGER (-)	TAN/RED	Harness In Passenger Kick Panel
LEFT REAR DOOR TRIGGER (-)	TAN/ORANGE or PURPLE/ORANGE	Harness In Driver's Kick Panel
RIGHT REAR DOOR TRIGGER (-)	TAN/YELLOW	Harness In Passenger Kick Panel
FACTORY ALARM ARM (Negative trigger through a 2000-ohm resistor)	LT.GREEN/ORANGE	Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM DISARM (Negative trigger through a 480- ohm resistor. Double pulse will unlock doors)	Same wire as arm	
TACHOMETER WIRE	Any wire NOT GREEN/ORANGE	At Fuel Injector Or Ignition coil
DIESEL WAIT-TO-START	DO NOT interface with the vehicle's wait-to-start wire. A pulse timer relay must be used to delay the remote start's activation.	
BRAKE WIRE (+)	WHITE/TAN	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	At Harness At Steering Column
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
Models with a gray ignition key are equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		
For Dodge Ram 2500 and 3500 models, refer to info on the 2001 Dodge Ram. Also, on 2002-Up diesel models, when installing a remote start, DO NOT interface with the vehicle's wait-to-start wire. A pulse timer relay must be used to delay the remote start's activation.		

WIRING INFORMATION: 2004 Dodge Ram

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V IGNITION WIRE	PINK/WHITE	Ignition Harness
SECOND 12V IGNITION WIRE	PINK/LT.GREEN	Ignition Harness
12V ACCESSORY WIRE	DARK/BLUE	Ignition Harness
SECOND ACCESSORY WIRE	PINK/YELLOW	Ignition Harness
THIRD ACCESSORY WIRE	PINK/YELLOW	Ignition Harness
There are two separate PINK/YELLOW accessory wires		
POWER DOOR LOCK AND UNLOCK	PURPLE/DK.GREEN	Harness In Driver's Kick Panel
The same wire is used to lock and unlock the doors. Lock is negative trigger through a 820-ohm resistor and unlock is a negative trigger through a 330-ohm resistor		
PARKING LIGHTS (Negative trigger through a 330 or 249-ohm resistor)	WHITE/LT.GREEN	Headlight Switch
DRIVER DOOR TRIGGER (-)	PURPLE	Harness In Driver's Kick Panel
PASSENGER DOOR TRIGGER (-)	PURPLE/WHITE	Harness In Passenger Kick Panel
LEFT REAR DOOR TRIGGER (-)	PURPLE/ORANGE	Harness In Driver's Kick Panel
RIGHT REAR DOOR TRIGGER (-)	PURPLE/YELLOW	Harness In Passenger Kick Panel
FACTORY ALARM ARM AND DISARM	PURPLE/LT.BLUE	Harness Coming Into Vehicle From Driver's Door
The same wire is used to arm and disarm the factory security. Arm is negative trigger through a 2000-ohm resistor. This will also lock the doors. Disarm is a negative trigger through a 480-ohm resistor. A double pulse will unlock the doors.		
TACHOMETER WIRE	DK.BLUE/GRAY	In Orange Connector At Module On Passenger Side Firewall Under Hood
TACHOMETER WIRE- DIESEL	DK.BLUE/GRAY	At Module On Driver's Side Of Engine Low
DIESEL WAIT-TO-START	DO NOT interface with the vehicle's wait-to-start wire. A pulse timer relay must be used to delay the remote start's activation.	
BRAKE WIRE (+)	WHITE/TAN	At Brake Pedal Switch
HORN TRIGGER (-)	DK.GREEN/PURPLE	At Harness At Steering Column
LEFT FRONT WINDOW UP	ORANGE/LT.GREEN	At Driver Window Switch Inside Door
LEFT FRONT WINDOW DOWN	ORANGE/WHITE	At Driver Window Switch Inside Door
RIGHT FRONT WINDOW UP	ORANGE/TAN	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	ORANGE/GRAY	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	ORANGE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	ORANGE/GRAY	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	ORANGE/LT.BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	ORANGE/BLUE	Harness In Driver's Kick From Driver Door
Models with a gray ignition key are equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2005 Dodge Ram

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V IGNITION WIRE	PINK/WHITE	Ignition Harness
SECOND 12V IGNITION WIRE	PINK/LT.GREEN	Ignition Harness
12V ACCESSORY WIRE	DARK/BLUE	Ignition Harness
SECOND ACCESSORY WIRE	PINK/YELLOW	Ignition Harness
THIRD ACCESSORY WIRE	PINK/YELLOW	Ignition Harness
There are two separate PINK/YELLOW accessory wires		
POWER DOOR LOCK AND UNLOCK	PURPLE/DK.GREEN	Harness In Driver's Kick Panel
The same wire is used to lock and unlock the doors. Lock is negative trigger through a 820-ohm resistor and unlock is a negative trigger through a 330-ohm resistor		
PARKING LIGHTS (Negative trigger through a 330 or 249-ohm resistor)	WHITE/LT.GREEN	Headlight Switch
DRIVER DOOR TRIGGER (-)	PURPLE	Harness In Driver's Kick Panel
PASSENGER DOOR TRIGGER (-)	PURPLE/WHITE	Harness In Passenger Kick Panel
LEFT REAR DOOR TRIGGER (-)	PURPLE/ORANGE	Harness In Driver's Kick Panel
RIGHT REAR DOOR TRIGGER (-)	PURPLE/YELLOW	Harness In Passenger Kick Panel
FACTORY ALARM ARM AND DISARM	PURPLE/LT.BLUE	Harness Coming Into Vehicle From Driver's Door
The same wire is used to arm and disarm the factory security. Arm is negative trigger through a 2000-ohm resistor. This will also lock the doors. Disarm is a negative trigger through a 480-ohm resistor. A double pulse will unlock the doors.		
TACHOMETER WIRE	DK.BLUE/GRAY	In Orange Connector At Module On Passenger Side Firewall Under Hood
TACHOMETER WIRE- DIESEL	DK.BLUE/GRAY	At Module On Driver's Side Of Engine Low
DIESEL WAIT-TO-START	DO NOT interface with the vehicle's wait-to-start wire. A pulse timer relay must be used to delay the remote start's activation.	
BRAKE WIRE (+)	WHITE/TAN	At Brake Pedal Switch
HORN TRIGGER (-)	DK.GREEN/PURPLE	At Harness At Steering Column
LEFT FRONT WINDOW UP	ORANGE/LT.GREEN	At Driver Window Switch Inside Door
LEFT FRONT WINDOW DOWN	ORANGE/WHITE	At Driver Window Switch Inside Door
RIGHT FRONT WINDOW UP	ORANGE/TAN	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	ORANGE/GRAY	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	ORANGE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	ORANGE/GRAY	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	ORANGE/LT.BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	ORANGE/BLUE	Harness In Driver's Kick From Driver Door
Models with a gray ignition key are equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		