


PARKING LIGHT WIRE (1996-2000 CHRYSLER AND DODGE MINIVAN AUTOLAMPS)



NOTE:

On 1996-2000 Chrysler, Dodge, and Plymouth minivans WITH auto-lamps a special interface is required. The BLACK/YELLOW wire at the light switch must be interrupted as a negative pulse is sent to the GREEN/WHITE or GREEN/RED wire at the light switch. Use two relays and wire as shown:



RELAY 1

PIN	CONNECTION
85	TO CHASSIS GROUND
86	TO (+) PARKING LIGHT OUTPUT FROM ALARM/REMOTE START SYSTEM
87	TO CHASSIS GROUND
87A	NO CONNECTION
30	TO GREEN/WHITE or GREEN/RED WIRE AT HEADLIGHT SWITCH

RELAY 2

PIN	CONNECTION
85	TO CHASSIS GROUND
86	TO (+) PARKING LIGHT OUTPUT FROM ALARM/REMOTE START SYSTEM
87	NO CONNECTION
87A	TO BLACK YELLOW WIRE – SWITCH SIDE
30	TO BLACK YELLOW WIRE – CAR SIDE

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarInstallExperts.com assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarInstallExperts.com assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.